

HW Getting Started Guide



PQ-MDS-QOC3 Module

July 2006: Rev. A

Contents

Contents	1
About This Document	1
Required Reading	1
Definitions, Acronyms, and Abbreviations	1
Step 1: Check HW kit contents	2
Step 2: Check switches and jumpers	3
Step 3: Configure J4-J7 for Multi- or Single-Device	4
Step 4: Connect to Platform I/O Board (PIB)	6
Step 5: Power up the PQ-MDS-QOC3 Module	6
Step 6: Connect optical cables in accordance with your specific needs	7
Step 7: Configure the PQ-MDS-QOC3 Module via the MPC83xx host card.	7

About This Document

This document shows how to connect the PQ-MDS-QOC3 and verify its basic operation, in a step by step format. Settings for switches and jumpers are shown, including configuring the PQ-MDS-QOC3 for multi-PHY support. This document describes Ver. PROTO-1 of the PQ-MDS-QOC31.0.

Required Reading

It is assumed that the reader is familiar with an MDS for a MPC83xx, the Platform I/O Board (PIB).

Definitions, Acronyms, and Abbreviations


DIP	Dual In-line Package	MDS	Modular Development System
EEPROM	Electrically Erasable, Programmable Read-Only Memory	PHY	Physical connection to ethernet
ENET	Ethernet	PIB	Platform I/O Board
ETH Phy	Ethernet Phy	PQ	PowerQUICC
HW	Hardware	QE	Quick Engine, a functional block in the MPC83xx line of chips
LD	Light emitting Diode	QOC3	Quad-OC3, supplies four OC3 connections
		USB	Universal Serial Bus

PQ-MDS-QOC3 Module

HW Getting Started Guide

Step 1: Check HW kit contents

1. PQ-MDS-QOC3 Module
2. Fiber Optic bridge ("patch cord")
3. Fiber Optic loop-back cord
4. Headers for multi-PHY connections (not shown)
5. PQ-MDS-QOC3 Module documentation



Step 2: Check switches and jumpers

Step 2.a: J2

Default factory setting is:

Pins 1-2 connected

Pins 3-4 connected

This setting configures the TXCLK to use the on-board clock oscillator.


Step 2.b: J3

Default factory setting is:

Pins 1-2 connected

Pins 3-4 connected

This setting configures the RXCLK to use the on-board clock oscillator.



Step 3: Configure J4-J7 for Multi- or Single-Device

These jumpers enable connections to support multi-device operation.

Each jumper has a unique signal type associated with it:

- J4: RxEn
- J5: RxClav
- J6: TxEn
- J7: TxClav


All four jumpers must be configured for the same type of operation. That is, either single-device to multi-PHY, or single-device to single-PHY. If single-device to multi-PHY is used, the same device must be configured for all four PHYs.

The jumpers are configured for this using special removable header connectors, included in the kit. There are several options possible:


- Single-Device: Device 0 (or 1 or 2 or 3) to all PHYs (Device 0 shown in diagram at right - factory default),
- Multi-Device: Device x to PHY x (also shown in diagram at right)

Verify that the appropriate header is connected. A single-device, single-PHY header is shown in the photo at right. Note the wire connections.

(cont'd on next page)





A single-device to single-PHY header is shown below.



(cont'd from previous page)

To connect headers, do the following:

1. Make sure you use the same type of header for all four jumpers.
2. Situate the header in the correct direction: wire connections should be parallel to the long side of the PQ-MDS-QOC3 Module, as shown in the photo at right.
3. If using single-device to multi-PHY, ensure that the transverse wire connections are on the correct side, as shown.
4. Press each header down by hand, as shown in photo, bottom right.





Step 4: Connect to Platform I/O Board (PIB)

The PQ-MDS-QOC3 Module can be connected to either the PMC0 or the PMC1 slot on the PIB. This allows for a more flexible configuration.

1. As shown, position the PQ-MDS-QOC3 Module above the PMC0 or PMC1 slot, and match the attachments on the PQ-MDS-QOC3 Module with those on the PIB.
2. Press down until the PQ-MDS-QOC3 Module snaps in place.

You can use the provided metal spacers to hold the PQ-MDS-QOC3 Module in position on the PIB. The metal spacers are optional. Use the spaces holes to connect each spacer.




Step 5: Power up the PQ-MDS-QOC3 Module

Note that power is supplied to the PQ-MDS-QOC3 Module via the PIB. Power up is done by connecting the PQ-MDS-QOC3 to the PIB.


- LD1: Displays a green light.
- LD2: Displays a yellow light.
- LD3: Displays a yellow light.

If any one of these LED's does not operate, the module is faulty, and should not be used.



Step 6: Connect optical cables in accordance with your specific needs.

(Optical loopback shown connected in figure)



Step 7: Configure the PQ-MDS-QOC3 Module via the MPC83xx host card.

For more information on working with the PQ-MDS-QOC3 Module and how to configure it, see:

- MPC83xx-MDS-PIB User's Manual
- CodeWarrior User's Manual

How to Reach Us:

USA/Europe/Locations Not Listed:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-521-6274 or 480-768-2130

Japan:

Freescale Semiconductor Japan Ltd.
Technical Information Center
3-20-1, Minami-Azabu, Minato-ku
Tokyo 106-8573, Japan
81-3-3440-3569

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
852-26668334

Home Page:

www.freescale.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Learn More: For more information about Freescale products, please visit www.freescale.com.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2006. All rights reserved.