

# ILDPUG

## i.MX Linux Distribution POC User Guide

Rev. L5.15.52\_2.1.0-LDP —  
25 November 2022

User guide

### Document information

Information	Content
Keywords	i.MX, Linux, Linux distribution, L5.15.52_2.1.0-LDP
Abstract	The i.MX Linux distribution build uses a Yocto-based meta layer to generate a desktop Proof of Concept (POC) image.



## 1 Overview

The i.MX Linux distribution build uses a Yocto-based meta layer to generate a desktop Proof of Concept (POC) image. It works together with i.MX release layer (`meta-imx`). It reuses the Linux BSP release framework to manage and generate the U-Boot bootloader, Linux kernel image, and i.MX root file system in desktop image build.

The i.MX desktop layer is named as `meta-nxp-desktop`. It is available in Github under the `nxp-imx` project (<https://github.com/nxp-imx>). The release version is managed by the [i.MX Release Manifest](#).

Similar to the i.MX release layer, to use the i.MX desktop layer, follow the instructions in the *Yocto Project Quick Start* found at [www.yoctoproject.org/docs/current/yocto-project-qs/yocto-project-qs.html](http://www.yoctoproject.org/docs/current/yocto-project-qs/yocto-project-qs.html).

`meta-nxp-desktop` inherits most of layer configuration from the i.MX release layer (`meta-imx`) directly. It also includes the required host tools and the compatible binary toolchains targeting on the desktop image.

The following is the information for the `meta-nxp-desktop` layer structure:

- `meta-nxp-desktop`
  - `classes`: The auxiliary installation tools running on host OS
  - `conf`: Desktop specific layer configuration beyond `meta-imx`
  - `dynamic-layer`: NXP additional update on open source tools and components
  - `recipe-xxx`: NXP-specific update on open source tools, applications, and libraries
  - `tools`: NXP desktop layer setup tool
  - `README.md`: i.MX desktop layer build instructions
  - `EULA.txt`: i.MX desktop demo license file
  - `SCR.txt`: i.MX desktop package and patch license description

## 2 Image Build

The i.MX desktop image build uses a similar method as the i.MX Yocto Project. For detailed information, see the *i.MX Yocto Project User's Guide* (IMXLXYOCTOUG).

Desktop image build uses different DISTRO configurations. The syntax for the `imx-setup-desktop.sh` script is as follows:

```
$ DISTRO=<distro name> MACHINE=<machine name> source imx-setup-desktop.sh -b <build dir>
```

The only DISTRO environment variable option is `imx-desktop-xwayland`. The MACHINE environment variable indicates the configuration file in the `conf/machine/${MACHINE}desktop.conf` file in the `meta-nxp-desktop` repo.

### 2.1 Installing the repository utility

To get the BSP, you need to install the repository.

```
$ mkdir ~/bin
$ curl https://storage.googleapis.com/git-repo-downloads/repo > ~/bin/repo
$ chmod a+x ~/bin/repo
```

```
$ PATH=${PATH}::~/bin
```

## 2.2 Downloading the Yocto Project BSP

To download the Yocto Project BSP:

```
$ mkdir desktop
$ cd desktop
$ repo init -u https://github.com/nxp-imx/imx-manifest -b imx-
linux-kirkstone -m imx-5.15.52-2.1.0_desktop.xml
$ repo sync
```

## 2.3 Creating a new build folder

To create a *new* build folder:

```
$ DISTRO=imx-desktop-xwayland MACHINE=imx8mpevk source imx-
setup-desktop.sh -b build-desktop
```

Table 1. Target build machines

Build machine	Target board
imx8mpevk	i.MX 8M Plus EVK
imx8mqevk	i.MX 8M Quad EVK
imx8mmevk	i.MX 8M Mini EVK
imx8mnevk	i.MX 8M Nano EVK
imx8qmmek	i.MX 8QuadMax MEK
imx8qxp0mek	i.MX 8QuadXPlus MEK with silicon revision C0 chip

## 2.4 Restarting a build environment

If a new terminal window is opened or the machine is rebooted after a build directory is set up, the setup environment script should be used to set up the environment variables and run a build again. The full `imx-setupdesktop.sh` is not needed.

```
$ cd desktop
$ source setup-environment <build-dir>
```

## 2.5 Building the image

To build the image:

```
$ bitbake imx-image-desktop
```

## 2.6 Building imx-boot and UUU

The build method is the same as the i.MX Yocto Project. For detailed information, see the *i.MX Linux User's Guide (IMXLUG)*.

### 3 Feature Integration

The i.MX desktop image integrates the following components (not limited to):

- i.MX kernel/boot-loader/connectivity integration  
All the information about the Linux Standard BSP features can be found in the *i.MX Linux User Guide* (IMXLUG).
- GPU hardware integration for desktop graphics  
Includes OpenGL ES, OpenGL, Vulkan, DRM, and GPU profiling and memory tool.
- GPU/NPU integration for compute, vision, and ML  
Includes OpenCL, OpenVX, and TensorFlow-Lite
- VPU/GStreamer integration for video player
- Audio codec integration
- ISP integration

### 4 Questions & Answers

#### 4.1 How to obtain the desktop build image?

NXP does not release desktop images due to the license. Users can build it with `meta-nxp-desktop`.

#### 4.2 How to solve the failure of fetching image or Git source?

Check if the host build machine can connect to the external website, or can export a proxy as follows:

```
$ export http_proxy=<your proxy address:port >  
$ export https_proxy=<your proxy address:port >
```

#### 4.3 How to update the SD image size in Yocto configuration?

You can add the following setting in `<build_dir>/conf/local.conf` to specify the image size:

```
IMAGE_ROOTFS_SIZE = "8388608"
```

#### 4.4 How to log in to the desktop system?

The default build creates the "user" account with the password "user". To change the account or password, uncomment and update `APTGET_ADD_USERS` in `<build_dir>/conf/local.conf`.

#### 4.5 How to enable Wi-Fi connection on desktop image?

Currently, Wi-Fi needs manual enablement with the following command:

```
sudo modprobe moal mod_para=nxp/wifi_mod_para.conf
```

After that, the user can configure Wi-Fi connection in desktop setting.

## 4.6 How to test GPU integration?

The test procedure is as follows:

1. Synchronize the board time. For example, to set new data to 12 May 2022 18:00:00, execute the following command as root user:

```
$ sudo date -s "12 MAY 2022 18:00:00"
```

2. Add an apt proxy if needed.

Add the following two lines to `/etc/apt/apt.conf.d/proxy.conf`.

```
Acquire::http::Proxy "http://  
username:password@address:port/";  
Acquire::https::Proxy "https://  
username:password@address:port/";
```

3. Perform the OpenCL demo.

```
sudo apt install clinfo -y
```

4. Perform the OpenGL demo.

```
sudo apt install glmark2-es2-wayland -y
```

## Revision History

This table provides the revision history.

Table 2. Revision History

Revision number	Date	Substantive changes
L5.10.9_1.0.0-desktop-alpha	05/2021	Initial release
L5.10.35_2.0.0-desktop-beta1	07/2021	Desktop Beta1 release
L5.10.52_2.1.0-desktop-beta2	11/2021	Desktop Beta2 release
L5.10.72_2.2.0-desktop	01/2022	Desktop GA release
L5.15.5_1.0.0-desktop	05/2022	Desktop GA release
L5.15.32_2.0.0-desktop	08/2022	Desktop GA release
L5.15.52_2.1.0-LDP	11/2022	Desktop POC GA release

## 5 Legal information

### 5.1 Definitions

**Draft** — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

### 5.2 Disclaimers

**Limited warranty and liability** — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

**Right to make changes** — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification. Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Terms and conditions of commercial sale** — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at <http://www.nxp.com/profile/terms>, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

**Export control** — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

**Suitability for use in non-automotive qualified products** — Unless this data sheet expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

**Translations** — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

**Security** — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at [PSIRT@nxp.com](mailto:PSIRT@nxp.com)) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

### 5.3 Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

**NXP** — wordmark and logo are trademarks of NXP B.V.

## Contents

---

<b>1</b>	<b>Overview .....</b>	<b>2</b>
<b>2</b>	<b>Image Build .....</b>	<b>2</b>
2.1	Installing the repository utility .....	2
2.2	Downloading the Yocto Project BSP .....	3
2.3	Creating a new build folder .....	3
2.4	Restarting a build environment .....	3
2.5	Building the image .....	3
2.6	Building imx-boot and UUU .....	3
<b>3</b>	<b>Feature Integration .....</b>	<b>4</b>
<b>4</b>	<b>Questions &amp; Answers .....</b>	<b>4</b>
4.1	How to obtain the desktop build image? .....	4
4.2	How to solve the failure of fetching image or Git source? .....	4
4.3	How to update the SD image size in Yocto configuration? .....	4
4.4	How to log in to the desktop system? .....	4
4.5	How to enable Wi-Fi connection on desktop image? .....	4
4.6	How to test GPU integration? .....	5
<b>5</b>	<b>Legal information .....</b>	<b>6</b>

---

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.

---