

PowerPC™

Application Note

Emulator Considerations When Designing with the MPC8xx

*Netcomm Applications
Freescale, Austin, Texas*

Introduction

When attaching an emulator to the MPC8xx, some emulator specific considerations are called for. These can in some cases be generic recommendations, but in certain cases will be unique to the emulator you have chosen. In all cases, refer to your specific supplier for their latest requirements.

The following information was provided by the emulator companies noted, and does not constitute an endorsement by Freescale. This information is provided as a warning and convenience to our customer, but in all cases, verify with the emulator supplier you have selected for the most up to date needs they have.

Emulator Considerations When
Designing with the MPC8xx
Application Note

Applied Micro Systems (AMC)

- When a Applied Microsystems Corporation (AMC) SuperTAP is connected using the mirror or LSA connection method, the SuperTAP uses the JTAG lines and uses the alternate set of DPI control lines. Therefore, JTAG lines are not available.
- When the AMC SuperTAP is connected using the direct chip replacement method, SuperTAP uses the normal DPI lines to control its processor.
- When using the AMC SuperTAP and to avoid conflicts between the DPI and JTAG lines we recommend removing the JTAG lines from the circuit with SuperTAP installed, or making the processor the first device in the scan chain and allow no other device to drive the Transfer Data Out (TDO) signal.
- It may be necessary to isolate the TDI line to prevent the SuperTAP from driving into the target scan chain and confusing other devices downstream.
- It may be necessary to pull the TRST* line to all other devices controlled by the SuperTAP to ground. This should assure a floating TDI signal will not cause false transitions to be clocked into the other devices.

Embedded Support Tools (EST) MPC8xx and EST's VisionICE

VisionICE 10 Pin BDM Support

Reset Configuration Issues:

- Actively drive the DBGIC (D9,D10) and DBPC (D11,D12), Hard Reset Configuration bits onto the bus to select the Multifunction I/O pin selection for target and Development Port. The values required to be driven onto these pins are based on the signals that have been routed to the 10 pin BGND connector.
- There are two BDM “Freeze “ signal schemes. Freescale's Option A is recommended by EST but, Option B is also supported for 10-pin BDM functionality. Option B is used as an alternative typically when target design uses PCMCIA Port B to eliminate pin conflicts on the “Freeze “ signal. Option B requires that the FRC bit in the SIUMCR = 0.

Option A: (DBGIC=3 DBPC=0 and MPC860 signal names used for example)

Pin 1 = IPB0/IWP0/VFLS0	Pin 2 = /SRESET (unused by EST)
Pin 3 = GND	Pin 4 = DSCK/TCK
Pin 5 = GND	Pin 6 = IP_B1/IWP1/VFLS1
Pin 7 = /HRESET	Pin 8 = DSDI/TDI
Pin 9 = VOD(unused by EST)	Pin 10 = DSDO/TDO

Option B: (DBGC = 0 or 1 and FRC = 0)

Pin 1 = FRZ//IRQ6	Pin 2 = /SRESET (unused by EST)
Pin 3 = GND	Pin 4 = DSCK
Pin 5 = GND	Pin 6 = FRZ//IRQ6
Pin 7 = /HRESET	Pin 8 = DSDI
Pin 9 = VOD (unused by EST)	Pin 10 = DSDO

- Physically locate the 10 pin connector as close as possible to the processor to minimize trace length and cross coupling of noise onto the BDM signals. Do not run high speed clocks or signals adjacent to the BDM communication signals.
- Ensure that the emulator (10-pin BGND pin 7, /HRESET) is connected directly the /HRESET signal of the processor. This will provide the ability for the emulator to drive and sense the status of /HRESET. The target design should only drive the /HRESET with open collector, open drain type devices. Note: /HRESET should not be tied to /PORESET. (The emulator drives the /HRESET and DSCK to enable BDM operation.)
- To guarantee that JTAG Mode is not accidentally invoked, connect a pull down (~ 10K) resistor on the /TRST signal and a pull-up (~10K) on the TMS signal. When the MPC's development port (BDM) is used, JTAG functionality is disabled. Designs that require both should have a Reset configuration scheme to support the two modes.

VisionICE Event System ,Trace Support (Optional Target Connection)

- The VisionICE Event System requires some of the multifunction MPC860 signals to function in a particular pin configuration modes. This pin configuration will provide detailed information on the processor's code execution when cache is enabled and disabled. Follow the 10-pin BDM recommendations listed previously for Option A plus specific pin assignments.
- The Hard Reset Configuration should actively drive the DBGK and DBPC to specific values. DBGC=3 - Configures the multifunction pins to function as VF0, VF1, VF2, /STS, AT0, AT1, AT2, AT3, OP3. DBPC= 0 - Configures the TCK/DSCK = DSCK, TDO/DSDO = DSDO, TDI/DSDI = DSDI. It's recommended to actively drive ALL signals of the Hard Reset Configuration word since, other physical connections will be made to the Data Bus when using EST's POD.
- The VisionICE Event System requires a processor CLKOUT for tracing Bus Cycles. Verify that the value in the SCCR (Bits 1 and 2) register are not disabling the CLKOUT from the processor.
- An electrically clean CLKOUT signal is required by the VisionICE Event System. The Clockout must be electrically connected to or a direct copy of MPC Clockout.. If re-driven, the Clockout must be generated via low skew zero propagation delay circuit (i.e. PLL Clock Driver). Typically, internal clock speed should be designed (and configured) to match external bus clock speed for optimum Event & Trace functionality. Contact EST for target designs employing split bus speeds.

General Physical Connection Considerations for EST

- Connection between the VisionICE Event System and the Target's MPC8xx is done in one of two ways. Other than the signals for BDM connection (Option A above.), the emulator also needs direct physical connection to the MPC's external Address, Data and Control pins. This can be accomplished by one of two methods. The first is to socket the MPC8xx processor and connect to the VisionICE to the socket using EST's Target Adapter product. The second and more convenient method is to design EST's recommended 80 pin connectors into the target design, thus eliminating the need for processor socketing. It's best to contact EST for this type of connection prior to designing the Target.

How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
 Technical Information Center, CH370
 1300 N. Alma School Road
 Chandler, Arizona 85224
 +1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
 Technical Information Center
 Schatzbogen 7
 81829 Muenchen, Germany
 +44 1296 380 456 (English)
 +46 8 52200080 (English)
 +49 89 92103 559 (German)
 +33 1 69 35 48 48 (French)
support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
 Headquarters
 ARCO Tower 15F
 1-8-1, Shimo-Meguro, Meguro-ku,
 Tokyo 153-0064
 Japan
 0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
 Technical Information Center
 2 Dai King Street
 Tai Po Industrial Estate
 Tai Po, N.T., Hong Kong
 +800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
 P.O. Box 5405
 Denver, Colorado 80217
 1-800-441-2447 or 303-675-2140
 Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

