

# **56F832x** BLDC Motor Control Application with Quadrature Encoder using Processor Expert™ *Targeting Document*

**56F8300**  
**16-bit Digital Signal Controllers**

832xBLDCQETD  
Rev. 0  
08/2005

[freescale.com](http://freescale.com)

## Document Revision History

Version History	Description of Change
Rev 0	Initial release

# BLDC Motor Control Application with Quadrature Encoder

This application exercises simple control of the BLDC motor with the Quadrature Encoder on the 56F8323EVMboard and the EVM Motor Kit.

*Applications developed for this demonstration board were not designed for the 56F8100 devices. The 56F8300 demonstration board does, however, fully support 56F8100 software development.*

## 1. Specifications

This application performs simple control of the BLDC motor with the Quadrature Encoder and closed-loop speed control on a 56F8322 or 56F8323 processor. In the application, the PWM module is set to complementary mode with a 16kHz switching frequency. The masking and swapping of PWM channels is controlled by the PWM Channel Control Register. The content of this register is derived from Quadrature Encoder signals. The required voltage is set independently on the commutation by the speed PI controller. The speed is measured by the Quadrature Timer. The RUN/STOP switch enables/disables motor spinning. The allowable range of speed is from 50rpm to 1000rpm in both directions.


The application can run on:

- Internal Flash

The BLDC Motor Control Application with Quadrature Encoder can operate in either of two modes; this EVM does not support both modes at the same time.

### 1. Manual Operating Mode

The drive is controlled by the RUN/STOP switch (S3). The motor speed is set by the UP (S1) and DOWN (S2) push buttons; see [Figure 1-1](#). If the application runs and motor spinning is disabled (i.e., the system is ready), the USER LED (LED18, shown in [Figure 1-2](#)) will blink. When motor spinning is enabled, the USER LED is on. Refer to [Table 1-1](#) for application states.



**Figure 1-1 RUN/STOP Switch and UP/DOWN Buttons on the Daughter Card**




Figure 1-2 USER and PWM LEDs on the Daughter Card

Table 1-1 Motor Application States

Application State	Motor State	Green LED State
Stopped	Stopped	Blinking at a frequency of 2Hz
Running	Spinning	On
Fault	Stopped	Blinking at a frequency of 8Hz

## 2. PC master software (Remote) Operating Mode

The drive is controlled remotely from a PC through the SCI communication channel of the device via an RS-232 physical interface. The drive is enabled by the RUN/STOP switch, which can be used to safely stop the application at any time.

The following control actions are supported:

- Set the Required Speed of the motor

PC master software displays the following information:

- Required Speed
- Actual Speed
- Applied Voltage
- DCBus Voltage
- RUN/STOP Switch Status

Application Mode Project files for the PC master software are located in project directory in: `..\PC_Master\sdm_pROM-xRAM PCMaster.pmp`, which uses the Map file to run in the small memory model of the internal flash memory

`..\PC_Master\sdm_xROM-xRAM PCMaster.pmp`, which uses the Map file to run in the small memory model of the internal flash memory

Start the PC master software window's application, `sdm_pROM-xRAM PCMaster.pmp`. **Figure 1-3** illustrates the PC master software control window after this project has been launched.




Figure 1-3 PC Master Software Control Window


## 2. Hardware Set-up

### 2.1 The Motor

The default hardware and software configuration is set up to support a BLDC motor with one wiring hole. Since there are two available motor types, please **check to see if your BLDC motor has a single wiring hole in the motor housing** from which the power stage and Hall Sensor connections are located (See motor photos in [Figure 2-1](#)). When using a BLDC motor with two wiring holes, **it is necessary to turn over the yellow power stage connector from the position shown in [Figure 2-2](#)** (left photo) to the inverted connection (right photo in [Figure 2-2](#)).



**Figure 2-1 Possible Motor Types**




**Figure 2-2 Default (left picture) and Inverted (right picture) Motor Cable Connections**



## 2.2 Application Hardware Setup

**Figure 2-3** illustrates the hardware set-up for the BLDC Motor Control Application with Quadrature Encoder.



**Figure 2-3 Set-up of the BLDC Motor Control Application**


For detailed information, see the **56F8323 Evaluation Module Hardware User's Manual**. The serial cable is needed for the PC master software debugging tool only.

## 2.3 EVM Jumper Settings

For jumper settings, see the **56F8323 Evaluation Module Hardware User's Manual**.

To execute the BLDC Motor Control Application with Quadrature Encoder, the 56F8300 Daughter Card requires the strap settings shown in **Figure 2-4** and **Table 2-1**.

**Note:** When running the EVM target system in a stand-alone mode from Flash, the JG3 jumper on the 56F8323EVM must be set in the 1-2 configuration to disable the command converter parallel port interface.



**Figure 2-4 56F8300EVM - Daughter Card Jumper Reference**


**Table 2-1 56F8300EVM Daughter Card Jumper Settings**

Jumper Group	Comment	Connections
JG1	Primary PFC	1-2, 3-4, 9-10 5-6 and 7-8 should NOT be jumpered
JG2	Secondary PFC	NC
JG3	Phase_IS / Over_I	1-2
JG4	Primary Zero-Crossing / Encoder	NC
JG5	Secondary Zero-Crossing / Encoder	2-3, 5-6, 8-9
JG6	Primary Back-EMF / Phase-IS	1-2, 4-5, 7-8
JG7	Secondary Back-EMF / Phase-IS	1-2, 4-5, 7-8
JG8	Fault A Monitor	1-2, 3-4, 5-6
JG9	Fault B Monitor	1-2, 3-4, 5-6
JG10	Switch 1	1-2
JG11	Switch 2	1-2
JG12	Switch 3 (Run / Stop)	1-2

### 3. Build


When building the BLDC Motor Control Application with Quadrature Encoder, the user creates an application that runs from internal Flash. The application will run with either PC master software control or with the on-board switches controlling the motor speed. To select the type of application to build, open the *bldc\_encoder.mcp* project and choose the target build type; see [Figure 3-1](#). A definition of the projects associated with these target build types may be viewed under the *Targets* tab of the project window.

**Note:** It is not possible for the 8323EVM to control the BLDC motor speed with both the switches and the PC master software in the same project. The signal used to sense SW2 on the LMDC board is the same signal that handles the SCI TXD1 communication.



**Figure 3-1 Target Build Selection**

The project may now be built by executing the *Make* command, as shown in [Figure 3-2](#). This will build and link the BLDC Motor Control Application with Quadrature Encoder and all needed Metrowerks and Processor Expert libraries.



**Figure 3-2 Execute *Make* Command**

For more information about these commands, see:

[<...>\CodeWarrior Manuals\PDF\Targeting\\_56800E.pdf](...>\CodeWarrior Manuals\PDF\Targeting_56800E.pdf)

## 4. Execute

To execute the BLDC Motor Control Application with Quadrature Encoder, select the *Project\Debug* command in the CodeWarrior IDE, followed by the *Run* command. For more help with these commands, refer to the CodeWarrior tutorial documentation in the following file, located in the CodeWarrior installation directory:

[<...>\CodeWarrior Manuals\PDF\Targeting\\_56800E.pdf](...>\CodeWarrior Manuals\PDF\Targeting_56800E.pdf)

CodeWarrior will automatically program the device's internal Flash with the executable generated during *Build*.

Once Flash has been programmed with the executable, the EVM target system may be run in a stand-alone mode from Flash. To do this on the 56F8323EVM, set jumper JG3 to disable the JTAG port, then push the RESET button.

Once the application is running, move the RUN/STOP switch to the RUN position, and set the required speed with the UP/DOWN push buttons. Pressing the UP/DOWN buttons should incrementally increase the motor speed until it reaches maximum speed. If successful, the BLDC motor will be spinning.

**Note:** If the RUN/STOP switch is set to the RUN position when the application starts, toggle the RUN/STOP switch between the STOP and RUN positions to enable motor spinning. This is a protection feature that prevents the motor from starting when the application is executed from CodeWarrior.

You should also see a lighted red LED (labeled FAULT B2), which indicates that the application is running. If the application is stopped, the red LED will blink at a 2Hz frequency. If an Undervoltage fault occurs, the red LED will blink at a frequency of 8Hz.







## **How to Reach Us:**

### **Home Page:**

www.freescale.com

### **E-mail:**

support@freescale.com

### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor  
Technical Information Center, CH370  
1300 N. Alma School Road  
Chandler, Arizona 85224  
+1-800-521-6274 or +1-480-768-2130  
support@freescale.com

### **Europe, Middle East, and Africa:**

Freescale Halbleiter Deutschland GmbH  
Technical Information Center  
Schatzbogen 7  
81829 Muenchen, Germany  
+44 1296 380 456 (English)  
+46 8 52200080 (English)  
+49 89 92103 559 (German)  
+33 1 69 35 48 48 (French)  
support@freescale.com

### **Japan:**

Freescale Semiconductor Japan Ltd.  
Headquarters  
ARCO Tower 15F  
1-8-1, Shimo-Meguro, Meguro-ku,  
Tokyo 153-0064, Japan  
0120 191014 or +81 3 5437 9125  
support.japan@freescale.com

### **Asia/Pacific:**

Freescale Semiconductor Hong Kong Ltd.  
Technical Information Center  
2 Dai King Street  
Tai Po Industrial Estate  
Tai Po, N.T., Hong Kong  
+800 2666 8080  
support.asia@freescale.com

### **For Literature Requests Only:**

Freescale Semiconductor Literature Distribution Center  
P.O. Box 5405  
Denver, Colorado 80217  
1-800-441-2447 or 303-675-2140  
Fax: 303-675-2150  
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. This product incorporates SuperFlash® technology licensed from SST.

© Freescale Semiconductor, Inc. 2004, 2005. All rights reserved.

832xBLDCQETD  
Rev. 0  
08/2005