

MC3359xMODxx Kit

by: Laurent Gauthier
Toulouse, France

1 Overview

This document provides introductory information for using MC3359x tools with HyperTerminal software. Windows software is also available to ease use. Please refer to related documentation for more information.

MC3359xMODxxx operation requires:

- An MC3359xMODxxx RF module with attached printed antenna
- A DEMO908AP64 MCU board
- An RS232 cable
- A PC with RS232 port, CD player, and HyperTerminal.
- A 9 V battery




Figure 1. MC3359xMODxx Kit

MC3359x operates by sending a script via HyperTerminal to the MCU board that configures MC3359x in a defined configuration.

Available script files:

- Standby configuration
- One frame reception using ID and HD

2 Launch the Kit

Perform these steps to launch the MC3359x:

1. Plug the RF module on the MCU board.
2. Connect the MCU board to the PC using the RS232 cable.
3. Launch HyperTerminal using the proper xxx.ht file according to the available COM port.
4. Connect the 9 V battery.

When these steps are complete, the HyperTerminal screen displays the status of MC3359x registers and pin levels (Figure 2).




Figure 2. MC3359x Registers and Pin-Level Status

3 Sending a Script File

To configure the kit in receive mode, perform these steps:

1. With the mouse, click Transfer/Send text file.
2. Select the xxx.txt script file corresponding to the desired configuration. For example: RX OOK 433.92 MHz IDHD00.txt configures the kit in receive mode at 433.92 MHz to receive any square-modulated signal at 4800 bps:
 - 433.92 MHz, OOK
 - Receive with data manager
 - ID=00h
3. Receive Mode Active indicates the kit is waiting for data.

If an RF signal is transmitted using another kit or a properly configured RF generator (433.92 MHz, pulse modulation at 4800 bps), the HyperTerminal screen fills with the received data (Figure 3).

THIS PAGE IS INTENTIONALLY BLANK

How to Reach Us:**Home Page:**

www.freescale.com

Web Support:

<http://www.freescale.com/support>

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc.
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
+1-800-521-6274 or +1-480-768-2130
www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-compliant and/or non-Pb-free counterparts. For further information, see <http://www.freescale.com> or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to <http://www.freescale.com/epp>.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.
© Freescale Semiconductor, Inc. 2007. All rights reserved.