





Jumper setting 1-2 for VDD through regulator and 2-3 for VDD supply through FRDM board.



All settings jumper position  
1-2 for operation with MCU and  
2-3 for manual operation.

