



September 3rd, 2020

FRDMSTBANBP8XD PACKING INSTRUCTIONS

Bill of materials reference Agile BOM 975-47506.

Step 1

Place board FRDMSTBANBP8XD (700-47506) into an ESD shielding bag as shown:



Not actual picture, reference image only.

Step 2

Place the bagged FRDMSTBANBP8XD board (700-47506) into Vendors choice Box/Foam Packaging materials (590-75025). Also place the QSG (924-76457) then the packing list (925-47506) into the box respectively.

Step 3

Place the PQ label (Agile PN 805-77462) and CE label (Agile PN 805-75208) on the bottom side of the box as shown:





No actual picture, reference image only.

This completes the pack out procedure.