



01-JUN-2021

PTN38003A-EVM Packing Instructions

Bill of Materials

Reference Agile BOM 975-47874

Agile PN	Description	Qty	Packed by:
700-47770	PWA, X-PTN38007-BASE	2	CM
700-50583	PWA, X-PTN38007EVM-TP	1	CM
925-47874	PACKING LIST, PTN38007-EVM	1	CM
924-76425	QUICK START GUIDE, ANALOG TOOLS	1	CM
805-77462	LABEL, PQ	1	CM
805-75208	LABEL, CE MARK	1	CM
590-46093	FOAM, FOR ICC-QMC-DGC BOARD USE WITH 570-46093 BOX	1	CM
570-46093	BOX, E-FLUTE (WHITE), 100x55x55mm	1	CM
Vendor's Choice	ESD STATIC SHIELDING BAG	1	CM
Vendor's Choice	PINK BUBBLE WRAP	AR	CM



Step 1 –

Assemble two boards as per below combination and place into an ESD Static Shielding as shown:

1x X-PTN38007EVM-TP (47771) **H2** board: 700-47771 (use PTN3800**3A**) + X-PTN38007-BASE (47770) : 700-47770
1x X-PTN38007EVM-TP (47771) **D2** board: 700-47771 (use PTN3800**3A**)+ X-PTN38007-BASE (47770) : 700-47770



Pictures are use as reference image only

Step 2 -

Wrap the board with Pink bubble wrap. Use enough so that the board is not loose in the box.



Pictures are use as reference image only



Step 3 –

Place the FOAM (590-46093) inside box and then Securely place the board inside box(570-46093) as shown

Place QUICK START GUIDE, ANALOG TOOLS(924-76425) by folding to accommodate inside the box

Place Packing List (925-47874) on top as shown:



Pictures are use as reference image only

Step 4 –

Close the box and apply PQ label (805-77462) on top side as shown below:



Pictures are use as reference image only



Step 5 –

Stick CE Mark (805-75208) on top side as shown below:



Pictures are use as reference image only

This completes pack out