

Building a PDK 1.0 Development Platform

For additional information, see the topic “Build the Platform” in the *i.MX27 PDK 1.0 Quick Start Guide*.



Step 1: Remove the four screws from the “Demo” configuration back enclosure. Retain the screws.



Step 2: Gently rock the CPU card back and forth to remove.



Step 3: Install the Debug board onto the Personality board.



Step 4: Reinstall the CPU board



Step 5a: Firmly twist to screw in the two plastic standoffs into the “Demo” top enclosure’s mounting holes on the opposite side of the 500-pin connector. This will stabilize the entire assembly.



Step 5b: Another view of the development configuration. Note the location of the standoffs.



Step 6: You are done!

Save the screws to use when you want to return to the “Demo” configuration.

