

Interfacing the MSC8101 UPM to an External Dual-Port SRAM

By Iantha Scheiwe

The MSC8101 is a powerful DSP that integrates the StarCore™ SC140 DSP core, a communications processor module (CPM) for network interfacing, and a system interface unit (SIU). The SIU memory controller includes three user-programmable machines (UPMs). Each UPM controls access to a wide array of memory types, including both synchronous and asynchronous SRAM and DRAM memories.

This application note describes the interface between the MSC8101 UPM and the Cypress CY7C028V dual-port asynchronous SRAM (DPRAM). After a review of UPM and DPRAM basics, it considers the signals interfacing between the two devices as well as the timing diagrams for the interface. The section on the UPM programming model includes programming specifics for the DPRAM interface. After you program the memory controller, you can access the memory in multiple ways from the MSC8101.

CONTENTS

1	UPM and DPRAM Basics	2
2	UPM Programming Model	3
2.1	UPM RAM Array	3
2.2	Timing Interface Diagrams	4
2.2.1	MSC8101 to DPRAM Single Read Timing	4
2.2.2	MSC8101 to DPRAM Single Write Timing	6
2.2.3	DPRAM Semaphore Read After Write Timing ..	7
2.2.4	Timing Diagram of Read with BUSY	8
2.3	RAM Words	10
2.3.1	Read	13
2.3.2	Write	14
2.3.3	Exception	14
2.4	UPM Registers	14
2.5	RAM Array Programming	16
2.6	Memory Controller Bank Registers	16
2.6.1	BRx Register	16
2.6.2	ORx Register	18
3	UPM Programming Steps	19
4	Memory Access	20
5	Conclusions	20
6	References.....	21

1 UPM and DPRAM Basics

The UPM allows the system designer to program the memory controller signal activity to each 1/2 or 1/4 PowerPC system bus clock cycle so that the UPM can interface to any number of different types of memories. The MSC8101 has three UPMs: UPMA, UPMB, UPMC. UPMC is used on the internal PowerPC local bus to control the interface to internal SRAM from the PowerPC local bus. UPMC is initialized at boot-up so that non-core resources can access the internal SRAM. UPMC is not available for use with external devices. However, UPMA and UPMB are available for access to external devices on the PowerPC system bus.

The Cypress CY7C028V Dual-Port RAM (DPRAM) is an asynchronous SRAM that allows two independent devices to gain access to the SRAM simultaneously through its dual ports. The memory device has two independent sets of address, data, and control lines that allow two devices to access a memory cell. Because the two accessing devices are independent, each can have a unique hardware interface and timing requirement. DPRAM devices include extra functions not found in a standard SRAM that allow one accessing device to lock out a memory cell from the other accessing device if required.

The UPM has six unique signals, PGPL[0–5]. The UPM can use other signals associated with memory accesses as well, including chip selects and byte selects. **Figure 1** shows the UPM signals. The PGPL4 signal requires special programming because it can function as an input when it is not required as a PGPL signal.




Figure 1. UPM Signals

The MSC8101 UPM signal actions are highly programmable. The chip select (\overline{CS}) and byte select (\overline{PBS}) signals shown in **Figure 1** are programmable to a PowerPC bus 1/4 clock cycle. The General-Purpose Line (PGPL[0–5]) signals are programmable to the 1/2 clock cycle.

Because the CY7C028V is a dual-ported SRAM, **Figure 2** shows how two MSC8101 devices can connect to the SRAM device. The DPRAM uses standard SRAM signals such as chip-select (chip enable), read/write, address, and data lines to define the interface as well as some signals that are required to service the dual ports. Chip-select 4 ($\overline{CS4}$) connects to the semaphore (\overline{SEM}) signal from the DPRAM. Through this signal, the DPRAM controls which device accesses a semaphore latch at a given time. The semaphore latches are memory-mapped separately via the $\overline{CS4}$ signal, and the DPRAM device handles semaphore priority. Therefore, the semaphore can keep two DSP devices from over-writing a specific memory location.




Figure 2. Dual MSC8101 UPM to CY7C028V DPRAM Signal Interface

The PUPMWAIT signal is the UPM PGPL4 signal that allows an external device to freeze the external signals until the PUPMWAIT signal is released (or the system bus reaches a time-out condition). Therefore, the DPRAM can assert its \overline{BUSY} signal and hold the MSC8101 transaction until the memory location is released and the MSC8101 writes to the desired location. Upper byte (\overline{UB}) and Lower byte (\overline{LB}) signals on the DPRAM connect to the MSC8101 byte select (PBS[0-1]) signals. Therefore, both 8-bit and 16-bit accesses are possible. The DPRAM can generate an interrupt to the MSC8101 via the \overline{IRQ} signal.

2 UPM Programming Model

This section discusses the various modules within the UPM and registers that must be programmed to implement a UPM transaction. **Section 3**, *UPM Programming Steps*, on page 19 lists the UPM programming steps.

2.1 UPM RAM Array

Each UPM has a memory bank designated for programming it. This memory bank is called the UPM RAM array and is not memory-mapped but is instead programmed through a sequence of register writes. Six types of memory accesses can be programmed: single read, burst read, single write, burst write, refresh, and exception. Each access is allotted a designated amount of space within the RAM array. **Table 1** lists the starting addresses in the RAM array for each access type. These addresses are used in programming the Machine Mode Register, which is discussed later.

Table 1. UPM Routine Start Addresses

UPM Routine	Routine Start Address
Read single-beat (RSS)	0x00
Read burst (RBS)	0x08
Write single-beat (WSS)	0x18
Write burst (WBS)	0x20
Refresh timer (PTS)	0x30
Exception condition (EXS)	0x3C

Because the DPRAM is an SRAM without burst capabilities, the burst read and burst write access types do not require programming. Also, the refresh access is not required. **Section 2.3**, *RAM Words*, on page 10 describes the steps for programming the applicable access types in the RAM array. The RAM array is programmed with RAM words that define signal interface timing at each 1/4 bus clock. Examples of this are given in **Section 3**, *UPM Programming Steps*, on page 19.

2.2 Timing Interface Diagrams

Creating timing diagrams of the memory interface access types makes the UPM programming procedure easier. Since the UPM signals are programmable to 1/2 and 1/4 clock cycles, it helps to refer to the completed timing diagrams when determining the programming for the access types. Therefore, creating the timing diagrams is the first step in programming the UPM RAM array.¹ The MSC8101 PowerPC system bus operates at a maximum speed of 100 MHz. A 15 ns access time DPRAM is specified for this timing analysis. The following diagrams are discussed here:

- Single Read Timing
- Single Write Timing
- Semaphore Read after Write Timing
- Read with $\overline{\text{BUSY}}$

2.2.1 MSC8101 to DPRAM Single Read Timing

Figure 3 shows the timing diagram for the read cycle. **Table 2** shows the parameters related to these timing specifications. Notice that the UPM allows programming of the PGPLn , $\overline{\text{PBSn}}$, and $\overline{\text{CSn}}$ lines for each 1/4 or 1/2 clock cycle. Because of this, derived clocks for each 1/4 clock cycle are shown (T_n). Also, MSC8101 output timings are rated for 50 pf. Timings based on a 50 pf load are appropriate for a single DPRAM device on the PowerPC system bus. However, if a multi-device system is sharing the PowerPC system bus, it is important to analyze capacitive loading on the bus and choose the timings appropriately.

In the following timing diagrams all timings with numerical names are MSC8101 timings derived from information in the MSC8101 data sheet. Timings with alphabetical names are specified timings for the Cypress DPRAM and can be found in the data sheet for this device. The diagrams should be developed with these data sheets in hand. The “#” notation used with the signal names to the left of the diagram is a convention used to show

1. An application note entitled *Using DSP56300 Interactive Timing Diagrams* (AN1834) is available on the Freescale website. This application note describes using TimingDesigner from Chronology to evaluate interface timings. Refer to this application note if you are unfamiliar with timing analysis or the TimingDesigner tool.

low assertion. Therefore, UB# is the same as $\overline{\text{UB}}$. TimingDesigner does not support overlines on their text, so the “#” notation is used instead. Signal names to the left of the “/” are the DPRAM signal names. Signal names to the right are the associated MSC8101 signal names.




Figure 3. Single Read Cycle Timing

Table 2. Single Read Cycle Timing Parameters

Row	Name	Min	Max	Comment
1	V DSP_Name			Freescale MSC8101 Digital Signal Processor
2	V MEMORY_Name			Cypress CY7C028V Dual-Port Static RAM 64kx16, 15ns
3	V Doc_Reference1			MSC8101 Advance Information, Rev 0.5
4	V Doc_Reference2			Preliminary CY7C027V/028V Data Sheet
5	V Mode_Description			UPM Single Read to Dual-Port SRAM, 15ns access time
12	C tRC	15		Read Cycle Time
13	D tLZCE	3		$\overline{\text{CE}}$ low to low Z
14	D tLZCE	3		$\overline{\text{CE}}$ low to low Z
15	G tOHA	3		Output hold from address change
16	D tAA		15	Address to data valid
17	D tACE		15	CE low to data valid
18	D tABE		15	Byte enable access time
19	D tHZCE		10	$\overline{\text{CE}}$ high to high Z
20	D tHZCE		10	$\overline{\text{CE}}$ high to high Z

Table 2. Single Read Cycle Timing Parameters (Continued)

Row		Name	Min	Max	Comment
21	C	t10	0.5		SIU hold
22	C	t12a	4.55		Data bus in normal mode, input_DLLin, setup
23	D	t32	0.5	8.5	ADD/ADD_atr/CI/GBL/WT/output_DLLin
24	D	t34	0.5	5.5	memc_signals/DLE,V_CKL
25	D	t34	0.5	5.5	memc_signals/DLE,V_CKL
26	D	t34	0.5	5.5	memc_signals/DLE,V_CKL
27	D	t34	0.5	5.5	memc_signals/DLE,V_CKL

2.2.2 MSC8101 to DPRAM Single Write Timing

Figure 4 shows the timing diagram for the write cycle. Following the diagram, **Table 3** shows the parameters related to these timing specifications.




Figure 4. Single Write Cycle Timing

Table 3. Single Write Cycle Timing Parameters


Row		Name	Min	Max	Margin	Comment
1	V	DSP_Name				Freescale MSC8101 Digital Signal Processor
2	V	MEMORY_Name				Cypress CY7C028V Dual-Port Static RAM 64kx16, 15ns
3	V	Doc_Reference1				MSC8101 Advance Information, Rev 0.5
4	V	Doc_Reference2				Preliminary CY7C027V/028V Data Sheet
5	V	Mode_Description				UPM Single Write to Dual-Port SRAM, 15ns access time
6	V	Aliases				

Table 3. Single Write Cycle Timing Parameters (Continued)

Row	Name	Min	Max	Margin	Comment
12	C	tWC	15		<17,> Write Cycle Time
13	C	tAW	12		<15,> Address valid to write end
14	C	tSCE	12		<8,> Write pulse width
15	C	tSA	0		<2,> Address set-up to write start
16	C	tSD	10		<17,> Data set-up to write end
17	C	tHD	0		<0,> Data hold from write end
18	C	tHA	0		<0,> Address hold from write end
19	D	t32	0.5	8.5	ADD/ADD_atr/CI/GBL/WT/output_DLLin
20	D	t34	0.5	5.5	memc_signals/DLE,V_CKL
21	D	t33a	0.5	8.5	Data bu, output_DLLin s
22	D	t34	0.5	5.5	memc_signals/DLE,V_CKL
23	D	t34	0.5	5.5	memc_signals/DLE,V_CKL

2.2.3 DPRAM Semaphore Read After Write Timing

Figure 5 shows the timing diagram for the semaphore read after write cycle. Following the diagram, **Table 4** shows the parameters related to these timing specifications.


Figure 5. Semaphore Read After Write Timing

Notice that this is a chip-select controlled write so it varies slightly from the associated diagram shown in the CY7C028V data sheet.

Table 4. Semaphore Read After Write Timing Parameters

Row		Name	Min	Max	Margin	Comment
1	V	DSP_Name				Freescale MSC8101 Digital Signal Processor
2	V	MEMORY_Name				Cypress CY7C028V Dual-Port Static RAM 64kx16, 15ns
3	V	Doc_Reference1				MSC8101 Advance Information, Rev 0.5
4	V	Doc_Reference2				Preliminary CY7C027V/028V Data Sheet
5	V	Mode_Description				UPM, Semaphore Read after Write timing, 15ns access time
12	C	tAW	12		<15,>	Address valid to write end
13	C	tSCE	12		<8,>	CE# low to write end
14	C	tSD	10		<17,>	Data set-up to write end
15	C	tHA	0		<0,>	Address hold from write end
16	C	tPWE	12		<18,>	Write pulse width
17	C	tHD	0		<0,>	Data hold from write end
18	C	tSOP	10		<5,>	SEM flag update pulse (OE or SEM)
19	C	tSWRD	5		<10,>	SEM flag write to read time
20	C	tACE		15	<,7>	CE low to data valid
21	C	tSA	0		<2,>	Address set-up to write start
22	D	tOHA	3			Output hold from address change
23	D	tSAA		15		SEM address access time
24	C	t10	0.5		<3,>	SIU hold
25	C	t12a	4.55		<1.95,>	Data bus in normal mode, input_DLLin, setup
26	D	t32	0.5	8.5		ADD/ADD_atr/CI/GBL/WT/output_DLLin
27	D	t33a	0.5	8.5		Data bu, output_DLLin s
28	D	t34	0.5	5.5		memc_signals/DLE,V_CKL
29	D	t34	0.5	5.5		memc_signals/DLE,V_CKL
30	D	t34	0.5	5.5		memc_signals/DLE,V_CKL
31	D	t34	0.5	5.5		memc_signals/DLE,V_CKL
32	D	t34	0.5	5.5		memc_signals/DLE,V_CKL

2.2.4 Timing Diagram of Read with $\overline{\text{BUSY}}$

The DPRAM $\overline{\text{BUSY}}$ signal connects to the MSC8101 PUPMWAIT signal, which is sampled on the falling edge of the MSC8101 bus clock signal. To enable PUPMWAIT, set the Machine Mode Register bit 13, MxMR[13] and set UPM RAM words, bits 18 and 19, to 1. Setting bit 18 directs the MSC8101 to sample the data bus at the rising edge of T3. Setting bit 19 directs the MSC8101 to freeze an external signal logical value if the PUPMWAIT signal is detected. **Figure 6** shows the timing diagram for the read cycle with $\overline{\text{BUSY}}$. **Table 5** shows the parameters related to these timing specifications.




Figure 6. Timing Diagram of Read with $\overline{\text{BUSY}}$

Table 5. Timing Parameters of Read with $\overline{\text{BUSY}}$

Row	Name	Min	Max	Margin	Comment
1	V DSP_Name				Freescale MSC8101 Digital Signal Processor
2	V MEMORY_Name				Cypress CY7C028V Dual-Port Static RAM 64kx16, 15ns
3	V Doc_Reference1				MSC8101 Advance Information, Rev 0.5
4	V Doc_Reference2				Preliminary CY7C027V/028V Data Sheet
5	V Mode_Description				UPM, Timing of Read with BUSY, 15ns access time
12	C tWC	15		<17,>	Write Cycle Time
13	C tPWE	12		<8,>	Write pulse width
14	C tSD	10		<17,>	Data set-up to write end
15	C tHD	0		<0,>	Data hold from write end
16	C tPS	5		<9.5,>	Port set-up for priority
17	D tBLA		15		BUSY low from address match
18	D tBHA		15		BUSY high from address mismatch
19	D tBDD		15		BUSY high to data valid
20	D tDDD		25		Write data valid to read data valid
21	D tWDD		30		Write pulse to data delay
22	C t10	0.5		<2.5,>	SIU hold
23	C t12a	4.55		<9.45,>	Data bus in normal mode, input_DLLin, setup
24	C t12a	4.55		<1.95,>	All other pins, input_DLLin, setup

Table 5. Timing Parameters of Read with $\overline{\text{BUSY}}$ (Continued)

Row	Name	Min	Max	Margin	Comment
25	D t32	0.5	8.5		ADD/ADD_atr/Ci/GBL/WT/output_DLLin
26	D t32	0.5	8.5		ADD/ADD_atr/Ci/GBL/WT/output_DLLin
27	D t33a	0.5	8.5		Data bu, output_DLLin s
28	D t34	0.5	5.5		memc_signals/DLE,V_CKL
29	D t34	0.5	5.5		memc_signals/DLE,V_CKL

2.3 RAM Words

Once the timing diagrams for each access type are defined, the UPM signals can be programmed based on those diagrams. The timing for each signal is defined by the RAM word for each cycle of the access. The RAM word, shown in **Figure 7**, is a 32-bit microinstruction stored in one of 64 locations in the RAM array. It specifies timing for signals controlled by the UPM.

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
CST1	CST2	CST3	CST4	BST1	BST2	BST3	BST4	G0L	G0H	G1T1	G1T3	G2T1	G2T3		
Bit	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
16															
G3T1	G3T3	G4T1/ DLT3	G4T3/ WAEN	G5T1	G5T3	REDO	LOOP	EXEN	AMX	NA	UTA	TODT	LAST		

Figure 7. RAM Word

Table 6 describes the RAM word fields.

Table 6. RAM Word Bit Descriptions

Name	Description	Settings
CST1 0	Chip-Select Timing 1 Defines the state of $\overline{\text{CS}}$ during clock phase 1.	0 At the rising edge of T1 $\overline{\text{CS}}$ is zero. 1 At the rising edge of T1 $\overline{\text{CS}}$ is one.
CST2 1	Chip-Select Timing 2 Defines the state of $\overline{\text{CS}}$ during clock phase 2.	0 At the rising edge of T2 $\overline{\text{CS}}$ is zero. 1 At the rising edge of T2 $\overline{\text{CS}}$ is one.
CST3 2	Chip-Select Timing 3 Defines the state of $\overline{\text{CS}}$ during clock phase 3.	0 At the rising edge of T3 $\overline{\text{CS}}$ is zero. 1 At the rising edge of T3 $\overline{\text{CS}}$ is one.
CST4 3	Chip-Select Timing 4 Defines the state of $\overline{\text{CS}}$ during clock phase 4.	0 At the rising edge of T4 $\overline{\text{CS}}$ is zero. 1 At the rising edge of T4 $\overline{\text{CS}}$ is one.
BST1 4	Byte-Select Timing 1 Defines the state of $\overline{\text{PBS}}$ during clock phase 1. The final value of the $\overline{\text{PBS}}$ lines depends on the values of BRx[PS], the TSIZ lines, and A[30–31] for the access.	0 At the rising edge of T1 $\overline{\text{PBS}}$ is zero. 1 At the rising edge of T1 $\overline{\text{PBS}}$ is one.
BST2 5	Byte-Select Timing 2 Defines the state of $\overline{\text{PBS}}$ during clock phase 2. The final value of the $\overline{\text{PBS}}$ lines depends on the values of BRx[PS], TSIZx, and A[30–31] for the access.	0 At the rising edge of T2 $\overline{\text{PBS}}$ is zero. 1 At the rising edge of T2 $\overline{\text{PBS}}$ is one.
BST3 6	Byte-Select Timing 3 Defines the state of $\overline{\text{PBS}}$ during clock phase 3. The final value of the $\overline{\text{PBS}}$ lines depends on the values of BRx[PS], TSIZx, and A[30–31] for the access.	0 At the rising edge of T3 $\overline{\text{PBS}}$ is zero. 1 At the rising edge of T3 $\overline{\text{PBS}}$ is one.

Table 6. RAM Word Bit Descriptions (Continued)

Name	Description	Settings
BST4 7	Byte-Select Timing 4 Defines the state of $\overline{\text{PBS}}$ during clock phase 4. The final value of the $\overline{\text{PBS}}$ lines depends on the values of $\text{BRx}[\text{PS}]$, TSIZx , and $\text{A}[30-31]$ for the access.	0 At the rising edge of T4 $\overline{\text{PBS}}$ is zero. 1 At the rising edge of T4 $\overline{\text{PBS}}$ is one.
G0L 8–9	General-Purpose Line 0 Lower Defines the state of PGPL0 during phases 1–2.	00 The value of PGPL0 at the rising edge of T1 is as defined in $\text{MxMR}[\text{G0CL}]$. 10 The value of the PGPL0 line at the rising edge of T1 is zero. 11 The value of the PGPL0 line at the rising edge of T1 is one.
G0H 10–11	General-Purpose Line 0 Higher Defines the state of PGPL0 during phase 3–4.	00 The value of PGPL0 at the rising edge of T3 is as defined in $\text{MxMR}[\text{G0CL}]$. 10 The value of the PGPL0 line at the rising edge of T3 is zero. 11 The value of the PGPL0 line at the rising edge of T3 is one.
G1T1 12	General-Purpose Line 1 Timing 1 Defines the state of PGPL1 during phase 1–2.	0 At the rising edge of T1 PGPL1 is zero. 1 At the rising edge of T1 PGPL1 is one.
G1T3 13	General-Purpose Line 1 Timing 3 Defines the state of PGPL1 during phase 3–4.	0 At the rising edge of T3 PGPL1 is zero. 1 At the rising edge of T3 PGPL1 is one.
G2T1 14	General-Purpose Line 2 Timing 1 Defines the state of PGPL2 during phase 1–2.	0 At the rising edge of T1 PGPL2 is zero. 1 At the rising edge of T1 PGPL2 is one.
G2T3 15	General-Purpose Line 2 Timing 3 Defines the state of PGPL2 during phase 3–4.	0 At the rising edge of T3 PGPL2 is zero. 1 At the rising edge of T3 PGPL2 is one.
G3T1 16	General-Purpose Line 3 Timing 1 Defines the state of PGPL3 during phase 1–2.	0 At the rising edge of T1 PGPL3 is zero. 1 At the rising edge of T1 PGPL3 is one.
G3T3 17	General-Purpose Line 3 Timing 3 Defines the state of PGPL3 during phase 3–4.	0 At the rising edge of T3 PGPL3 is zero. 1 At the rising edge of T3 PGPL3 is one.
G4T1/ DLT3 18	General-Purpose Line 4 Timing 1/Delay Time 2 Function is determined by $\text{MxMR}[\text{PGPLx4DIS}]$.	If MxMR defines $\text{PUPMWAITx}/\text{PGPL}_x4$ as an output (PGPL_x4), this bit functions as G4T1 : 0 The value of the PGPL4 line at the rising edge of T1 is zero. 1 The value of the PGPL4 line at the rising edge of T1 is one. If $\text{MxMR}[\text{PGPLx4DIS}] = 1$, PUPMWAITx is chosen and this bit functions as DLT3 . 0 In the current word, indicates that the data bus should be sampled at the rising edge of T1 (if a read burst or a single read service is executed). 1 In the current word, indicates that the data bus should be sampled at the rising edge of T3 (if a read burst or a single read service is executed).

Table 6. RAM Word Bit Descriptions (Continued)

Name	Description	Settings
G4T3/ WAEN 19	General-Purpose Line 4 Timing 3/Wait Enable Function depends on the value of MxMR[PGPLx4DIS].	<p>If MxMR[PGPLx4DIS] = 0, G4T3 is selected.</p> <p>0 The value of the PGPL4 line at the rising edge of T3 is zero.</p> <p>1 The value of the PGPL4 line at the rising edge of T3 is one.</p> <p>If MxMR[PGPLx4DIS] = 1, WAEN is selected.</p> <p>0 The PUPMWAITx function is disabled.</p> <p>1 A freeze in the external signals logical value occurs if the external <u>WAIT</u> signal is asserted. This condition lasts until <u>WAIT</u> is deasserted.</p>
G5T1 20	General-Purpose Line 5 Timing 1 Defines the state of PGPL5 during phase 1–2.	<p>0 At the rising edge of T1 PGPL5 is zero.</p> <p>1 At the rising edge of T1 PGPL5 is one.</p>
G5T3 21	General-Purpose Line 5 Timing 3 Defines the state of PGPL5 during phase 3–4.	<p>0 At the rising edge of T3 PGPL5 is zero.</p> <p>1 At the rising edge of T3 PGPL5 is one.</p>
REDO 22–23	Redo Current RAM Word	<p>00 Normal operation.</p> <p>01 The current RAM word is executed twice.</p> <p>10 The current RAM word is executed three times.</p> <p>11 The current RAM word is executed four times.</p>
LOOP 24	Loop The first RAM word in the RAM array where LOOP is one is recognized as the loop start word. The next RAM word where LOOP is one is the loop end word. RAM words between the start and end are defined as the loop. The number of times the UPM executes this loop is defined in the corresponding loop field of the MxMR.	<p>0 The current RAM word is not the loop start word or loop end word.</p> <p>1 The current RAM word is the start or end of a loop.</p>
EXEN 25	Exception Enable	<p>0 The UPM continues executing the remaining RAM words.</p> <p>1 The current RAM word allows a branch to the exception pattern after the current cycle if an exception condition is detected.</p>
AMX 26–27	Address Multiplexing Determines the source of A[0–31] at the rising edge of T1 (single-MCS8101 mode only).	<p>00 A[0–31] is the non-multiplexed address. For example, column address.</p> <p>01 Reserved.</p> <p>10 A[0–31] is the address requested by the internal master multiplexed according to MxMR[AMx]. For example, row address.</p> <p>11 A[0–31] is the contents of MAR. Used, for example, during SDRAM mode initialization.</p>
NA 28	Next Address Determines when the address is incremented during a burst access. The value of NA is relevant only when the UPM serves a burst-read or burst-write request. NA is reserved under other patterns.	<p>0 The address increment function is disabled.</p> <p>1 The address is incremented in the next cycle.</p>
UTA 29	UPM Transfer Acknowledge Indicates assertion of <u>PSDVAL</u> , sampled by the bus interface in the current cycle.	<p>0 <u>PSDVAL</u> is not asserted in the current cycle.</p> <p>1 <u>PSDVAL</u> is asserted in the current cycle.</p>

Table 6. RAM Word Bit Descriptions (Continued)

Name	Description	Settings	
TODT 30	Turn-On Disable Timer	0	The disable timer is turned off.
		1	The disable timer for the current bank is activated preventing a new access to the same bank (when controlled by the UPMs) until the disable timer expires.
LAST 31	Last If this bit is set, it is the last RAM word in the program. When the LAST bit is read in a RAM word, the current UPM pattern terminates and the highest priority pending UPM request (if any) is serviced immediately in the external memory transactions.	0	The UPM continues executing RAM words.
		1	The service to the UPM request is done.

After the RAM words for each cycle of each access type are determined, the RAM array can be programmed. The following sections give the RAM word values for each access type to DPRAM and the MSC8101 code to program the RAM words into the UPM RAM array.

Note: PUPMWAIT does not appear in the timing diagrams shown in **Section 2.2**, but it is programmed in the RAM words. This is because its functionality must be enabled for the PGPL4 signal, but as shown in **Figure 7**, this functionality does not have specific clock cycle timing such as is required for the other PGPL and \overline{CS} signals.

2.3.1 Read

Figure 3 shows that the single read cycle is a 3-cycle access (from the first address transition until the next address transition is three PowerPC system bus clock cycles). Therefore, three RAM words are required, one for each cycle of the memory access. For each RAM word, the programmer is accounting for signal activity at every 1/4 clock of the system bus clock (T1, T2, T3, T4). **Table 1** shows that these RAM words are programmed at offset 0x00 in the RAM array.

- Single Read Cycle RAM word 1: 0x00F03040
 \overline{CS} and \overline{PBS} signals are asserted at the beginning of the access, and are programmed to 0 starting from T1. PGPL0 remains unasserted for a READ cycle. PGPL4 is programmed to operate as PUPMWAIT. Exceptions are enabled for each cycle of the READ access.
- Single Read Cycle RAM word 2: 0x00F03040
 \overline{CS} and \overline{PBS} signals remain asserted during the second clock cycle of the read access, and remain programmed to 0. PGPL0 remains unasserted for the entire READ cycle. PGPL4 is programmed to operate as PUPMWAIT.
- Single Read Cycle RAM word 3: 0x33F03041
 $\overline{CS3}$ and $\overline{BS3}$ signals are deasserted at T3. PGPL4 is programmed as PUPMWAIT. This is the last RAM word for the single read access.

2.3.2 Write

Figure 4 shows the timing interface for the single write. The single write access is a 4 cycle access, so four RAM words are required to define the write interface. **Table 1** shows that these RAM words are programmed at offset 0x18 in the RAM array.

- Single write cycle RAM word 1: 0xEE03040
Program $\overline{CS3}$, $\overline{PBS3}$, and PGPL0 (R/W) signals to remain unasserted until T3. PGPL4 is programmed as PUPMWAIT.
- Single write cycle RAM word 2: 0x00A03040
Signals remain asserted throughout second cycle of access. PGPL4 still acts as PUPMWAIT.
- Single write cycle RAM word 3: 0x00A03040
Same as previous RAM word.
- Single write cycle RAM word 4: 0x33B03041
 $\overline{CS3}$, $\overline{PBS3}$, and PGPL0 become unasserted at T3. PGPL4 acts as PUPMWAIT. This is the last RAM word for the single write access.

2.3.3 Exception

An exception access can be programmed, depending on the requirements for the memory interface. **Table** shows that these RAM words are programmed at offset 0x3C in the RAM array.

- Exception cycle RAM word 1: 0xFF000001. Deassert $\overline{CS3}$ and PBS3 signals and end access.

2.4 UPM Registers

Besides the RAM words programmed in the UPM RAM array and BR and OR registers, two other UPM registers, the Memory Data Register (MDR) and the Machine *x* Mode Registers (MxMR) are used when the UPM is programmed. The MDR contains data written to or read from the RAM array for UPM READ or WRITE commands. MDR must be set up before a WRITE command is issued to the UPM. The MDR is a 32-bit register that holds the memory data information. Data to be written into the RAM array when a WRITE command is supplied to the UPM should be placed in the MDR before the write access is initiated.

The MxMR, shown in **Figure 8**, contain the configuration for the UPMs. The configuration includes selecting the bus that the memory is assigned to, specifying whether refresh is required, and specifying the multiplex information used primarily for access to DRAMs. Also, this register defines how many times looping RAM words should be repeated. When programming the RAM array, you inform the UPM that it is being programmed at a given RAM array address by setting the Command Opcode bits (OP) to the RAM array access function and the Machine Address (MAD) bits to the address in the RAM array being accessed.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	
BSEL	RFEN	OP	—	AMx			DSx		G0CLx			GPL_x4DIS		RLFx	
Bit 16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
RLFx		WLFx				TLFx				MAD					

Figure 8. Machine *x* Mode Registers (MxMR)

Table 7 describes MxMR bits.

Table 7. Machine x Mode Registers (MxMR) Bit Descriptions

Name	Description	Bit Settings
BSEL 0	Bus Select Assigns banks that select UPMx to the PowerPC system or local bus.	0 Banks that select UPMx are assigned to the system bus. 1 Banks that select UPMx are assigned to the local bus.
RFEN 1	Refresh Enable	0 Refresh services are not required 1 Refresh services are required
OP 2–3	Command Opcode Determines the command executed by the UPMx when a memory access hit a UPM assigned bank.	00 Normal operation. 01 Write to array. On the next memory access that hits a UPM assigned bank, write the contents of the MDR into the RAM location to which MAD points. After the access, the MAD field is automatically incremented. 10 Read from array. On the next memory access that hits a UPM assigned bank, read the contents of the RAM location to which MAD points into the MDR. After the access, the MAD field is automatically incremented 11 Run pattern. On the next memory access that hits a UPM assigned bank, run the pattern written in the RAM array. The pattern run starts at the location to which MAD points and continues until the LAST bit is set in the RAM.
AMx 5–7	Address Multiplex Size	
DSx 8–9	Disable Timer Period	
G0CLx 10–12	General Line 0 Control Determines which address line can be output to the PGPL0 pin when the UPMx is selected to control the memory access.	000 A12 001 A11 010 A10 011 A9 100 A8 101 A7 110 A6 111 A5
GPL_x4DIS 13	GPL_4 Output Line Disable Determines whether the PUPMWAIT/ $\overline{\text{GT}}\overline{\text{A}}$ /PGPL_4 pin behaves as an output line controlled by the corresponding bits in the UPMx array (PGPL4x).	0 PUPMWAIT/ $\overline{\text{GT}}\overline{\text{A}}$ /PGPL_x4 behaves as PGPL_4. UPMx[G4T4/DLT3] is interpreted as G4T4. The UPMx[G4T3/WAEN] is interpreted as G4T3. 1 PUPMWAIT/ $\overline{\text{GT}}\overline{\text{A}}$ /PGPL_x4 behaves as PUPMWAIT. UPMx[G4T4/DLT3] is interpreted as DLT3. UPMx[G4T3/WAEN] is interpreted as WAEN. Note: After a system reset, PGPL_x4DIS = 1.

Table 7. Machine x Mode Registers (MxMR) Bit Descriptions (Continued)

Name	Description	Bit Settings
RLFx 14–17	Read Loop Field Determines the number of times a loop defined in the UPMx executes for a burst- or single-beat read pattern or when MxMR[OP] = 11 (RUN command)	0001 The loop is executed 1 time 0010 The loop is executed 2 times ... 1111 The loop is executed 15 times 0000 The loop is executed 16 times
WLFx 18–21	Write Loop Field Determines the number of times a loop defined in the UPMx executes for a burst- or single-beat write pattern.	0001 The loop is executed 1 time 0010 The loop is executed 2 times ... 1111 The loop is executed 15 times 0000 The loop is executed 16 times
TLFx 22–25	Refresh Loop Field Determines the number of times a loop defined in the UPMx executes for a refresh service pattern.	0001 The loop is executed 1 time 0010 The loop is executed 2 times ... 1111 The loop is executed 15 times 0000 The loop is executed 16 times
MAD 26–31	Machine Address RAM address pointer for the command executed. This field is incremented by 1 each time the UPM is accessed and the OP field is set to WRITE or READ.	

2.5 RAM Array Programming

When the MxMR register is programmed to “write to array” mode (MxMR[OP]=01), any access to the memory space defined by the Base Register (BR) and Option Register (OR) causes the data currently residing the Memory Data Register (MDR) to be placed in the UPM RAM array at the address defined by the MxMR:MAD bits. **Section 3, UPM Programming Steps**, on page 19 details the code required for each step of programming the MSC8101 for a UPM interface to DPRAM.

2.6 Memory Controller Bank Registers

The Option Register (OR) and Base Register (BR) define the memory address in the MSC8101 memory map and general memory controller functions.

2.6.1 BRx Register

The base registers (BR0–7, 10, 11) contain the base address and address types that the memory controller uses to compare the address bus value with the current address accessed. Notice that there are no BR8 and BR9 registers. These two banks are reserved on the MSC8101. Each register also includes a memory attribute and selects the machine for memory operation handling. **Figure 9** shows the BRx register format.




Figure 9. Base Registers (BRx)

Table 8 describes BRx fields.

Table 8. BRx Bit Descriptions

Name	Description	Settings
BA 0–16	Base Address The upper 17 bits of each base address register are compared to the address on the address bus to determine if the bus master is accessing a memory bank controlled by the memory controller. BRx[BA] is used with ORx[BSIZE].	
PS 19–20	Port Size Specifies the port size of this memory region.	01 8-bit 10 16-bit 11 32-bit 00 64-bit
DECC 21–22	Data Error Correction and Checking Specifies the method for data error checking and correction.	00 Data errors checking disabled 01 Normal parity checking 10 Read-modify-write parity checking 11 ECC correction and checking
WP 23	Write Protect Can restrict write accesses within the address range of a BR. An attempt to write to this address range while WP = 1 can cause TEA to be asserted by the bus monitor logic (if enabled) which terminates the cycle. When WP is set, the memory controller does not assert CSx and PSDVAL on write cycles to this memory bank. TESC1[WP] or L_TESC1[WP] is set if a write to this memory bank is attempted	0 Read and write accesses are allowed 1 Only read access is allowed
MS 24–26	Machine Select Specifies machine select for the memory operations handling and assigns the bank to the PowerPC system bus if GPCM or SDRAM are selected. If UPMx is selected, the bus assignment is determined by MxMR[BSEL].	000 GPCM— system bus 001 GPCM—local bus 010 SDRAM— system bus 011 Reserved 100 UPMA 101 UPMB 110 UPMC 111 Reserved
EMEMC 27	External MEMC Enable Overrides MSEL and assigns the bank to the PowerPC system bus. When this bit is set, the external memory controller is expected to assert AACK, TA, and PSDVAL.	0 Accesses are handled by the memory controller according to MSEL 1 Accesses are handled by an external memory controller (or other slave) on the system bus

Table 8. BRx Bit Descriptions (Continued)

Name	Description	Settings
ATOM 28–29	Atomic Operation	00 The address space controlled by the memory controller bank is not used for atomic operations 01 Read-after-write-atomic (RAWA) 10 Write-after-read-atomic (WARA) 11 Reserved
DR 30	Data Pipelining	0 No data pipelining is done 1 Data beats of accesses to the address space controlled by the memory controller bank are delayed by one cycle.
V 31	Valid Bit Indicates that the contents of the BRx and ORx pair are valid. The \overline{CS} signal does not assert until V is set. An access to a region with no V bit set may cause a bus monitor time-out. After a system reset, BR0[V] is set.	0 This bank is invalid 1 This bank is valid

2.6.2 ORx Register

The ORx registers define the sizes of memory banks and access attributes.

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
AM															
Bit 16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
AM	—	BCTLD	—	—	—	—	BI	—	—	—	—	—	EHTR	—	—

Figure 10. ORx in UPM Mode

Table 9 describes the ORx fields in UPM mode.

Table 9. Option Register (ORx) in UPM Mode Bit Descriptions

Name	Description	Settings
AM 0–16	Address Mask Masks corresponding BRx bits. Masking address bits independently allows external devices of different size address ranges to be used. Address mask bits can be set or cleared in any order in the field, allowing a resource to reside in more than one area of the address map. AM can be read or written at any time.	0 Corresponding address bits are masked 1 The corresponding address bits are used in the comparison with address pins
BCTLD 19	Data Buffer Control Disable Disables the assertion of BCTLx during access to the current memory bank.	0 \overline{BCTLx} is asserted upon access to the current memory bank 1 \overline{BCTLx} is not asserted upon access to the current memory bank
BI 23	Burst Inhibit Indicates if this memory bank supports burst accesses.	0 The bank supports burst accesses 1 The bank does not support burst accesses The UPMx executes burst accesses as series of single accesses

Table 9. Option Register (ORx) in UPM Mode Bit Descriptions

Name	Description	Settings
EHTR 29–30	Extended Hold Time on Read Accesses Indicates how many cycles are inserted between a read access from the current bank and the next access.	00 Normal timing is generated by the memory controller. No additional cycles are inserted 01 One idle clock cycle is inserted 10 Four idle clock cycles are inserted 11 Eight idle clock cycles are inserted

3 UPM Programming Steps

Each step in programming the UPM includes accompanying example code for reference:

1. Evaluate interface timings to determine if the UPM is required. See **Section 2.2** for reference. These diagrams include single read and single write as described in this document, but they may also include burst read and write as well as read-after-write diagrams.

2. Program BRx and ORx for the chosen UPM operation at the desired memory address.

```
IMM->memc_regs[3].br = 0xC00018A1; /*place at 0xC0000000,
                                port size = 32 bits, UPMB, valid bank*/
IMM->memc_regs[3].or = 0xFFFF9004; /*64k device, does not
                                support burst */
```

3. Determine RAM word settings for each type of access required (single read, burst read, and so on).

Single Write Access RAM Word 1 = 0xEEEE03040

CS and PBS low at T4, PGPL0 low at T3, sample data bus at rising edge of T3

Single Write Access RAM Word 2 = 0x00A03040

CS, PBS, and PGPL0 low throughout cycle, sample bus at rising edge of T3

Single Write Access RAM Word 3 = 0x00A03040

Single Write Access RAM Word 4 = 0x33B03041

CS, PBS, and PGPL0 high at T3, sample bus at rising edge of T3, exceptions enabled, last RAM word

4. Program MxMR for the chosen UPM (that is, MAMR for UPMA, MBMR for UPMB). Set the OP bits to 01 for the write operation. Set the Machine Address to the access type address given in **Table 1**.

```
IMM->memc_mbmr = 0x10004458; /*PowerPC system bus, write */
```

5. Program the first RAM word (that is, the first cycle of the single write access) into the Memory Data Register (MDR).

```
IMM->memc_mdr = 0xEEEE03040; /* first RAM word placed in MDR*/
```

6. Perform a random move operation to an address within the range specified by BR and OR for the device. This move operation activates the UPM associated with the device, and the data from the MDR is placed into the RAM array at the address specified by the MBMR:MAD bits. The RAM array address automatically increments so it is ready for the next RAM word.

```
mem_ptr = (unsigned long int *)0xC0000000; /*initialize ptr to
                                beginning of mem*/
*mem_ptr = 0xFFFFFFFF; /*move random value to memory space,
                                RAM word will be written to RAM array */
```

7. Continue the move operations to the memory space until the entire RAM array is programmed for each access type. Once one access type is complete, be sure to change the MBMR:MAD address to the next access type before initiating the next move to the UPM memory space.

```
*IMM->memc_mdr = 0x00A03040;
*mem_ptr = 0xFFFFFFFF; /* move random value to memory space,
```

```

                                second RAM word is written to
                                RAM array */
IMM->memc_mdr = 0x00A03040;
*mem_ptr = 0xFFFFFFFF;          /* move random value to memory
                                space, RAM word will be
                                written to RAM array */

IMM->memc_mdr = 0x33B03041;
*mem_ptr = 0xFFFFFFFF;          /*move random value to memory
                                space, fourth RAM word is written to
                                RAM array at single write */

```

8. Program the MBMR:OP to normal operation.

```
*IMM->memc_mbmnr = 0x00004440;
```

Now you can access the memory device as usual.

4 Memory Access

The SC140 core can access the DPRAM using a move instruction such as those described in **Section 3**, *UPM Programming Steps*. This move operation allows the SC140 core to access the external memory directly if needed for either a data save to external memory or a data retrieval from external memory. Also, program code can be placed in external memory, and the SC140 core can execute from external memory. However, accessing external memory is not an efficient use of the SC140 core. Ideally, in DSP applications, the SC140 core is free from memory retrieval and is used for algorithmic processing. The Direct Memory Access Engine (DMA) handles data transfers from external memory to internal memory so that the SC140 core can operate primarily from internal memory, thus improving system efficiency.

DMA access to the Dual-Port SRAM is no different from other types of DMA accesses. Once the DMA controller has access to the bus, the transaction acts as a PowerPC system bus transaction according to the timings shown in **Section 2.2**. If the DMA channel's Buffer Descriptor Address (BD_ADDR) value matches the memory controller bank associated with the DPRAM, then the UPM activates the appropriate \overline{CS} signal. The DMA controller requests access to the bus. The *MSC8101 User's Guide* includes a chapter that shows examples of programming the DMA controller for various applications, including transfers from external memory on the PowerPC system bus to internal SRAM on the MSC8101.

A system application may require a data transfer between two devices resident on the PowerPC system bus. If both of these devices have the same port size, the flyby mode of the DMA can be used. Flyby mode does not require the intermediate FIFO step required by a regular DMA channel. Be sure to consider DMA flyby mode if the system requires transfer between memories or other devices on the PowerPC system bus.

A separate DMA engine, SDMA, resides within the CPM portion of the MSC8101. SDMA can initiate data transfers between the Cypress DPRAM discussed in this document and the CPM communication controllers. A system application can use the CPM communication controllers to bring data into the device. If the data does not reside entirely in internal SRAM, SDMA can be used to transfer the data to the Cypress DPRAM on the 60x-compatible system bus until the SC140 core requires it for processing.

5 Conclusions

To make the most of the UPM strengths, you must understand the programming steps required to initialize the UPM properly. This application note presents the registers and RAM array that must be programmed to operate the UPM and describes the steps required to complete the program. An example illustrates the programming steps. The UPM is a powerful memory interface machine that enables flexible system design.

6 References

- [1] *MSC8101 Reference Manual.*
- [2] Cypress, CY7C028V Datasheet.
- [3] Cypress, *Understanding Asynchronous Dual-Port RAMs.*
- [4] *MSC8101 Technical Data* sheet (MSC8101)

NOTES:

NOTES:

How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations not listed:

Freescale Semiconductor
Technical Information Center, CH370
1300 N. Alma School Road
Chandler, Arizona 85224
+1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GMBH
Technical Information Center
Schatzbogen 7
81829 München, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064, Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T. Hong Kong
+800 2666 8080

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. StarCore is a trademark of StarCore LLC. All other product or service names are the property of their respective owners.

© Freescale Semiconductor, Inc. 2001–2004.