



# **LPRF Board API Reference Manual**

JN-RM-2003  
Revision 2.4  
31 October 2016



---

# Contents

<b>Preface</b>	<b>7</b>
Organisation	7
Conventions	7
Acronyms and Abbreviations	8
Related Documents	8
Support Resources	8
Trademarks	8
<b>1. Introduction</b>	<b>9</b>
1.1 Software Installation	9
1.2 Board Types	9
1.3 API Organisation and Location	10
<b>2. Light Sensor Functions</b>	<b>11</b>
vALSreset	12
vALSstartReadChannel	13
u16ALSreadChannelResult	14
vALSpowerDown	15
<b>3. Temperature/Humidity Sensor Functions</b>	<b>17</b>
vHTSreset	18
vHTSstartReadTemp	19
u16HTSreadTempResult	20
vHTSstartReadHumidity	21
u16HTSreadHumidityResult	22
<b>4. LED Functions</b>	<b>23</b>
4.1 General LED Functions	23
vLedInitRfd	24
vLedInitFfd	25
vLedControl	26
4.2 RGB and White LED Functions (DR1175 only)	27
bRGB_LED_Enable	28
bRGB_LED_Disable	29
bRGB_LED_SetLevel	30
bRGB_LED_On	31
bRGB_LED_Off	32
bRGB_LED_SetGroupLevel	33
bPCA9634_Init	34

## Contents

bPCA9634_SetChannelLevel	35
bPCA9634_SetGroupLevel	36
bWhite_LED_Enable	37
bWhite_LED_Disable	38
bWhite_LED_SetLevel	39
bWhite_LED_On	40
bWhite_LED_Off	41
<b>5. Button Functions</b>	<b>43</b>
vButtonInitRfd	44
vButtonInitFfd	45
u8ButtonReadRfd	46
u8ButtonReadFfd	47
<b>6. LCD Screen Functions</b>	<b>49</b>
6.1 LCD Screen and Data Display	49
6.1.1 Shadow Memory	50
6.1.2 LCD Font	50
6.1.3 LCD Bitmaps	50
6.2 Functions	52
vLcdResetDefault	53
vLcdReset	54
vLcdStop	55
vLcdClear	56
vLcdWriteText	57
vLcdWriteTextRightJustified	58
vLcdWriteInvertedText	59
vLcdWriteBitmap	60
vLcdPlotPoint	61
bLcdGetPixel	62
vLcdDrawLine	63
vLcdDrawCircle	64
vLcdFloodFill	65
vLcdRefreshAll	66
vLcdRefreshArea	67
vLcdContrastLevel	68
u8LcdCalcContrastLevel	69
vLcdBackLightEnable	70
vLcdGrabSpiBus	71
vLcdFreeSpiBus	72
vLcdPowerOff	73
vLcdPowerSavingMode	74
vLcdButtonInit	75
u8LcdButtonRead	76

## 7. Generic Board (DR1199) Functions

**77**

bPotEnable	78
u16ReadPotValue	79
bPotDisable	80
vGenericButtonInit	81
u8GenericButtonRead	82
vGenericLEDInit	83
vGenericLEDSetOutput	84

## **Contents**

---

## Preface

This manual provides a detailed reference for the NXP Low-Power Radio Frequency (LPRF) Board Application Programming Interface (API), which can be used by an application to interact with the resources of the boards supplied in NXP JN51xx development kits, evaluation kits and expansion kits. The LPRF Board API consists of C functions that can be used in an application that runs on a JN516x or JN517x wireless microcontroller which resides on a module attached to the board.

---

## Organisation

This manual consists of 7 chapters, as follows:

- [Chapter 1](#) introduces the LPRF Board API.
- [Chapter 2](#) describes the functions for controlling the light sensor on the Lighting/Sensor Expansion Board.
- [Chapter 3](#) describes the functions for controlling the temperature and humidity sensors on the Lighting/Sensor Expansion Board.
- [Chapter 4](#) describes the functions for controlling the LEDs on various boards.
- [Chapter 5](#) describes the functions for controlling the general-purpose buttons on the Carrier Boards.
- [Chapter 6](#) describes the functions for controlling the LCD panel on the LCD Expansion Boards.
- [Chapter 7](#) describes the functions for controlling the potentiometer, buttons and LEDs on the Generic Expansion Board.

---

## Conventions

Files, folders, functions and parameter types are represented in **bold** type.

Function parameters are represented in *italics* type.

Code fragments are represented in the `Courier New` typeface.



This is a **Tip**. It indicates useful or practical information.



This is a **Note**. It highlights important additional information.



This is a **Caution**. It warns of situations that may result in equipment malfunction or damage.

---

## Acronyms and Abbreviations

API	Application Programming Interface
FFD	Full Function Device
LED	Light Emitting Diode
LCD	Liquid Crystal Display
LPRF	Low-Power Radio Frequency
PAN	Personal Area Network
PWM	Pulse Width Modulation
RFD	Reduced Function Device
SDK	Software Developer's Kit

---

## Related Documents

JN-UG-3087	JN516x Integrated Peripherals API User Guide
JN-UG-3118	JN517x Integrated Peripherals API User Guide
JN-UG-3108	JN516x-EK004 Evaluation Kit User Guide
JN-UG-3121	JN517x-DK005 Development Kit User Guide
JN-RD-6036	Carrier and Expansion Boards Reference Design

---

## Support Resources

To access online support resources such as SDKs, Application Notes and User Guides, visit the Wireless Connectivity area of the NXP web site:

[www.nxp.com/products/interface-and-connectivity/wireless-connectivity](http://www.nxp.com/products/interface-and-connectivity/wireless-connectivity)

All NXP resources referred to in this manual can be found at the above address, unless otherwise stated.

---

## Trademarks

All trademarks are the property of their respective owners.

---

# 1. Introduction

The Low-Power Radio Frequency (LPRF) Board Application Programming Interface (API) contains C functions that can be used by an application which runs on a board from an NXP JN51xx development kit, evaluation kit or expansion kit, in order to interact with the on-board resources (e.g. temperature sensor, buttons, LEDs). The API can be used with a board equipped with a JN516x or JN517x microcontroller.

The LPRF Board API provides a thin layer above the registers used to control the board components. Several register accesses are encapsulated into a single function call. The API therefore allows use of the on-board components without a detailed knowledge of their operation.



**Note:** This manual does not describe the API for interacting with features found on the JN51xx chip itself (such as the UARTs and DACs). The API for interfacing with the on-chip resources is detailed in the appropriate *Integrated Peripheral API User Guide: JN-UG-3087* for JN516x and *JN-UG-3118* for JN517x.

---

## 1.1 Software Installation

The LPRF Board API is supplied in the NXP Software Developer's Kits (SDKs) for the JN51xx devices - for example, the JN517x ZigBee 3.0 SDK (JN-SW-4270). The LPRF Board API is therefore installed as part of the SDK installation.

Separate header files are provided for different groups of functions in the LPRF Board API. The relevant header files are referenced in the remaining chapters of this manual.

---

## 1.2 Board Types

NXP boards of the following types can be used with the Board API:

- DR1174 Carrier Board fitted with a JN516x module and one of:
  - DR1175 Lighting/Sensor Expansion Board
  - DR1199 Generic Expansion Board
  - DR1215/DR1201\* LCD Expansion Board
- OM15028 Carrier Board fitted with a JN517x module and one of:
  - DR1175 Lighting/Sensor Expansion Board
  - DR1199 Generic Expansion Board
  - DR1215/DR1201\* LCD Expansion Board

\* The LCD Expansion Board DR1215 replaced DR1201, but both are now discontinued. However, the Board API still supports both boards.

The board hardware is fully detailed in the *Carrier and Expansion Boards Reference Design (JN-RD-6036)*. The User Guides for the development/evaluation kits also contain useful information about the boards - see [“Related Documents” on page 8](#).



**Note:** The DR1174 Carrier Board is a ‘DK4’ generation board and the OM15028 Carrier Board is a ‘DK5’ generation board.

---

## 1.3 API Organisation and Location

The functions of the LPRF Board API are divided into groups which are described in separate chapters of this manual - they are:

- Light Sensor Functions ([Chapter 2](#))
- Temperature and Humidity Sensor Functions ([Chapter 3](#))
- LED Functions ([Chapter 4](#))
- Button Functions ([Chapter 5](#))
- LCD Screen Functions ([Chapter 6](#))
- Generic Expansion Board (DR1199) Functions ([Chapter 7](#))

The relevant header files for the functions are referenced at the start of each chapter. They can be found in the following location:

- The LPRF Board API header files for the ‘DK4’ type boards (e.g. DR1174) are located in:

**.../Platform/DK4/Include**

- The LPRF Board API header files for the ‘DK5’ type boards (e.g. OM15028) are located in:

**.../Platform/DK5/Include**

This directory and its contents are only available in SDKs for the JN517x devices (with part numbers of the form JN-SW-42xx).

- Header files that contain functions common to all boards are located in:

**.../Platform/Common/Include**



**Note:** In the JN516x and JN517x SDKs, the source code for the LPRF Board API is provided. This can be used as an illustration of how to interact with the JN516x/7x on-chip peripherals using functions of the Integrated Peripherals API.

## 2. Light Sensor Functions

The chapter describes the functions that can be used to interact with the ambient light sensor on the DR1175 Lighting/Sensor Expansion Board. This sensor provides an indication of the level of light falling on the board.

The functions are defined in the header file **AlsDriver.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028), depending on the type of Carrier Board to which the Lighting/Sensor Expansion Board is fitted.

The TAOS TSL2550 ambient light sensor used on the board contains two photo-diodes connected to two separate channels:

- The Channel 0 photo-diode is sensitive to both visible and infra-red light.
- The Channel 1 photo-diode is primarily sensitive to infra-red light.

The light-levels obtained from the two channels (*Ch0* and *Ch1*) can be combined to approximate the response of the human eye, which is sensitive to visible light but insensitive to infra-red light. This adjusted light-level (in units of lux) is given by:

$$\text{Lightlevel} = 0.39 \times (Ch0 - Ch1) \times e^{0.181R^2}$$

where  $R = Ch1 / (Ch0 - Ch1)$ .

The result of this calculation allows a second device to be controlled to match the sensitivities of the human eye, e.g. to control the back-light required for an LCD screen in the given ambient lighting conditions.

Typical channel values and the corresponding light-levels for different light sources are summarised in the following table:

Light Source Type	Ch0 Value	Ch1 Value	Light-level (lux)
Fluorescent	830	70	296
Daylight (in the shade)	900	340	204
Incandescent	960	670	43

**Table 1: Typical Light-Level Readings**

For more information on the light sensor, refer to the TAOS TSL2550 datasheet.

The light sensor functions are listed below, along with their page references:

Function	Page
<a href="#">vALSreset</a>	12
<a href="#">vALSstartReadChannel</a>	13
<a href="#">u16ALSreadChannelResult</a>	14
<a href="#">vALSpowerDown</a>	15

---

## **vALSreset**

---

```
void vALSreset(void);
```

### **Description**

This function is used to initialise the ambient light sensor and must be called before using any other light sensor function.

### **Parameters**

None

### **Returns**

None

---

## vALSstartReadChannel

---

```
void vALSstartReadChannel(uint8 u8Channel);
```

### Description

This function can be used to initiate a read on one of the two channels (Channel 0 or Channel 1) of the ambient light sensor.



**Tip:** In the Home Sensor Demonstration applications (supplied with some evaluation kits and available as Application Notes), only Channel 0 is used and after the first call to this function, the device continually restarts conversions (so there is no need to call it again).

The result from the initiated read can be obtained by calling the function **u16ALSreadChannelResult()**.

### Parameters

<i>u8Channel</i>	Channel to be read:
	0 - Channel 0
	1 - Channel 1

### Returns

None

---

## u16ALSreadChannelResult

---

```
uint16 u16ALSreadChannelResult(void);
```

### Description

This function can be used to obtain the result of the last read of the ambient light sensor initiated by **vALSstartReadChannel()**.

The returned result is a value in the range 0 to 4015.



**Note:** The results of consecutive reads of Channel 0 and Channel 1 can be used to estimate the visible light-level as perceived by the human eye. This calculation is shown at the beginning of this chapter.

### Parameters

None

### Returns

Integer value in the range 0 to 4015

---

## vALSpowerDown

---

```
void vALSpowerDown(void);
```

### Description

This function can be used to power down the ambient light sensor unit.

The function is helpful in minimising the current drawn by the board - for example, it should be called on a board which acts as an End Device before entering sleep mode.

### Parameters

None

### Returns

None

**Chapter 2**  
**Light Sensor Functions**

---

## 3. Temperature/Humidity Sensor Functions

The chapter describes the functions that can be used to interact with the temperature and humidity sensors on the DR1175 Lighting/Sensor Expansion Board:

- Temperature can be measured in the range 0 to 124°C.
- Relative humidity can be measured in the range 0-100%.

These two measurements are actually provided by a single sensor unit on the board.

The functions are defined in the header file **HtsDriver.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028), depending on the type of Carrier Board to which the Lighting/Sensor Expansion Board is fitted.

The temperature and humidity sensor functions are listed below, along with their page references:

<b>Function</b>	<b>Page</b>
<a href="#">vHTSreset</a>	18
<a href="#">vHTSstartReadTemp</a>	19
<a href="#">u16HTSreadTempResult</a>	20
<a href="#">vHTSstartReadHumidity</a>	21
<a href="#">u16HTSreadHumidityResult</a>	22

---

## **vHTSreset**

---

```
void vHTSreset(void);
```

### **Description**

This function is used to initialise the combined temperature and humidity sensor, and must be called before using any other temperature and humidity function.

### **Parameters**

None

### **Returns**

None

---

## vHTSstartReadTemp

---

```
void vHTSstartReadTemp(void);
```

### Description

This function can be used to initiate a read of the temperature sensor.  
The result from the initiated read can be obtained by calling the function **u16HTSreadTempResult()**.

### Parameters

None

### Returns

None

---

## **u16HTSreadTempResult**

---

```
uint16 u16HTSreadTempResult(void);
```

### **Description**

This function can be used to obtain the result of the last read of the temperature sensor initiated by **vHTSstartReadTemp()**.

**u16HTSreadTempResult()** blocks until the result is available.

The returned result is a value in the range 0 to 124°C.

### **Parameters**

None

### **Returns**

Integer value in the range 0 to 124

---

## vHTSstartReadHumidity

---

```
void vHTSstartReadHumidity(void);
```

### Description

This function can be used to initiate a read of the relative humidity sensor.  
The result from the initiated read can be obtained by calling the function **u16HTSreadHumidityResult()**.

### Parameters

None

### Returns

None

---

## **u16HTSreadHumidityResult**

---

```
uint16 u16HTSreadHumidityResult(void);
```

### **Description**

This function can be used to obtain the result of the last read of the relative humidity sensor initiated by **vHTSstartReadHumidity()**.

**u16HTSreadHumidityResult()** blocks until the result is available.

The returned result is a value in the range 0-100%.

### **Parameters**

None

### **Returns**

Integer value in the range 0 to 100

---

## 4. LED Functions

The chapter describes the functions that can be used to control LEDs on a board. There are functions for two categories of controllable LED:

- General LEDs controlled via JN51xx DIOs
- RGB LEDs controlled via PCA9634 LED driver chip (DR1175 board only)
- White LED cluster (DR1175 board only)

The functions for the above two LED categories are described below in [Section 4.1](#) and [Section 4.2](#) respectively.

---

### 4.1 General LED Functions

The functions described in this section can be used to control general-purpose LEDs via JN51xx DIOs. The controllable LEDs are located on the Carrier Board, as follows:

- On the **DR1174** Carrier Board, they are LEDs **D3 and D6**
- On the **OM15028** Carrier Board, they are LEDs **D2 and D3**

The functions are defined in the header file **LedControl.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028).

The General LED functions are listed below, along with their page references:

Function	Page
<a href="#">vLedInitRfd</a>	24
<a href="#">vLedInitFfd</a>	25
<a href="#">vLedControl</a>	26

---

## vLedInitRfd

---

```
void vLedInitRfd(void);
```

### Description

This function is used to initialise the two controllable LEDs on a Carrier Board and must be called before attempting to control the LEDs.



**Tip:** Either **vLedInitRfd()** or **vLedInitFfd()** can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.

### Parameters

None

### Returns

None

---

## vLedInitFfd

---

```
void vLedInitFfd(void);
```

### Description

This function is used to initialise the two controllable LEDs on a Carrier Board that and must be called before attempting to control the LEDs.



**Tip:** Either **vLedInitFfd()** or **vLedInitRfd()** can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.

### Parameters

None

### Returns

None

---

## vLedControl

---

```
void vLedControl(uint8 u8Led, bool_t bOn);
```

### Description

This function can be used to control (illuminate or extinguish) an individual LED. Before using this function, the LED initialisation function **vLedInitFfd()** or **vLedInitRfd()** must have been called.

### Parameters

<i>u8Led</i>	LED to be controlled: 0 - D3 (on DR1174) or D2 (on OM15028) 1 - D6 (on DR1174) or D3 (on OM15028)
<i>bOn</i>	Action to be applied to LED: TRUE - illuminate LED FALSE - extinguish LED

### Returns

None

## 4.2 RGB and White LED Functions (DR1175 only)

The DR1175 Lighting/Sensor Expansion Board features a variable-intensity RGB LED cluster and a variable-intensity White LED cluster.

The RGB LEDs are driven from a PCA9634 LED driver chip on the board. This driver has 8 channels, where channels 0, 1 and 2 control the blue, green and red LEDs, respectively (the remaining 5 channels can be used to drive PWM outputs on the header CN6).

The White LEDs are driven from the JN516x or JN517x device using the on-chip PWM Timers.

Functions are provided that allow the RGB and White LEDs to be controlled from an application running on a JN516x or JN517x device on the board. These functions are defined in the header files **LightingBoard.h** and **pca9634.h**. Depending on the type of the underlying Carrier Board, these files are located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028).

The LED functions are listed below, along with their page references:

Function	Page
<a href="#">bRGB_LED_Enable</a>	28
<a href="#">bRGB_LED_Disable</a>	29
<a href="#">bRGB_LED_SetLevel</a>	30
<a href="#">bRGB_LED_On</a>	31
<a href="#">bRGB_LED_Off</a>	32
<a href="#">bRGB_LED_SetGroupLevel</a>	33
<a href="#">bPCA9634_Init</a>	34
<a href="#">bPCA9634_SetChannelLevel</a>	35
<a href="#">bPCA9634_SetGroupLevel</a>	36
<a href="#">bWhite_LED_Enable</a>	37
<a href="#">bWhite_LED_Disable</a>	38
<a href="#">bWhite_LED_SetLevel</a>	39
<a href="#">bWhite_LED_On</a>	40
<a href="#">bWhite_LED_Off</a>	41



**Caution:** *The LEDs on the DR1175 board are very bright at maximum intensity. To avoid damage to your eyes, do not look into them directly for an extended period of time.*

---

## **bRGB\_LED\_Enable**

---

```
bool bRGB_LED_Enable(void);
```

### **Description**

This function is used to initialise the PCA9634 LED driver device.

This function must be called before using any of the other RGB LED functions.

### **Parameters**

None

### **Returns**

TRUE - driver successfully initialised

FALSE - driver failed to initialise

---

## **bRGB\_LED\_Disable**

---

```
bool bRGB_LED_Disable(void);
```

### **Description**

This function is used to disable the PCA9634 LED driver device.

### **Parameters**

None

### **Returns**

TRUE - driver successfully disabled

FALSE - driver failed to disable

---

## bRGB\_LED\_SetLevel

---

```
bool bRGB_LED_SetLevel(uint8 u8RedLevel,  
                        uint8 u8GreenLevel,  
                        uint8 u8BlueLevel);
```

### Description

This function can be used to set the RGB LED brightness level in the range 0 (dimkest) to 255 (brightest).

### Parameters

<i>u8RedLevel</i>	Red brightness level (0-255)
<i>u8GreenLevel</i>	Green brightness level (0-255)
<i>u8BlueLevel</i>	Blue brightness level (0-255)

### Returns

TRUE - success  
FALSE - fail

---

## **bRGB\_LED\_On**

---

```
bool bRGB_LED_On(void);
```

### **Description**

This function can be used to switch on the RGB LEDs. The RGB LED brightness levels will be set to the values previously configured using **bRGB\_LED\_SetLevel()**.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## **bRGB\_LED\_Off**

---

```
bool bRGB_LED_Off(void);
```

### **Description**

This function can be used to switch off the RGB LEDs.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## bRGB\_LED\_SetGroupLevel

---

```
bool bRGB_LED_SetGroupLevel(uint8 u8Level);
```

### Description

This function can be used to apply a global scaling factor (of less than or equal to 1) across all channels of the PCA9634 LED driver device on the DR1175 board. This allows the brightnesses of the LEDs of the RGB cluster to be scaled simultaneously by the same factor. The scaling factor parameter *u8Level* can be set to a value in the range 0 to 255. Once the function has been called, the brightness of each LED becomes  $u8Level/255$  of its original brightness (the brightness with no global scaling factor applied). The default value of *u8Level* is 255, corresponding to full brightness. A factor of 0 will extinguish the LEDs.

This feature is useful when the LEDs of the RGB cluster are set to different brightness levels in order to achieve a certain colour. The function allows the brightness of the LED cluster to be adjusted without affecting this colour.

Note that when calling the function multiple times, on each occasion the scaling factor is applied to the original brightness levels of the LED cluster. For example, calling the function first with a scaling factor of 128 will result in a brightness reduction to approximately 50% of the original brightness. Then calling the function again with a scaling factor of 192 will result in a brightness increase to approximately 75% of the original brightness.

Also note that the scaling factor is applied to channels 3-7 of the PCA9634 driver device (that may drive PWM outputs on header CN6), as well as to channels 0-2 used for the RGB cluster.

### Parameters

*u8Level*                      Brightness scaling factor in the range 0 to 255

### Returns

TRUE - success  
FALSE - fail

---

## bPCA9634\_Init

---

```
bool bPCA9634_Init(void);
```

### Description

This function is used to initialise the PCA9634 LED driver device and must be called before the RGB LED cluster on the DR1175 board can be controlled using any of the other RGB LED functions.



**Note:** The function **bRGB\_LED\_Enable()** is identical to **bPCA9634\_Init()** and may be called instead of this one.

### Parameters

None

### Returns

One of:

TRUE - driver successfully initialised

FALSE - driver failed to initialise

---

## bPCA9634\_SetChannelLevel

---

```
bool bPCA9634_SetChannelLevel(uint8 u8Channel,  
                               uint8 u8Level);
```

### Description

This function can be used to control one of the RGB LEDs on the DR1175 board by setting the brightness level for the LED, in the range 0 (dimpest) to 255 (brightest).

The function requires the relevant channel number for the LED, which must be 0 (blue), 1 (green) or 2 (red) for the RGB LED cluster. If another channel is specified (3-7) then the level of the relevant output will be set (if connected).



**Note:** The brightness level for the RGB channels may instead be set using a single call to function **bRGB\_LED\_SetLevel()**.

### Parameters

<i>u8Channel</i>	LED channel to be controlled, in the range 0-7 (where 0, 1, 2 correspond to the blue, green and red LEDs, respectively)
<i>u8Level</i>	Brightness level to which specified LED is to be set, in the range 0-255

### Returns

One of:

TRUE - brightness level successfully set

FALSE - brightness level not set

---

## bPCA9634\_SetGroupLevel

---

```
bool bPCA9634_SetGroupLevel(uint8 u8Level);
```

### Description

This function can be used to apply a global scaling factor (of less than or equal to 1) across all channels of the PCA9634 LED driver device on the DR1175 board. This allows the brightnesses of the LEDs of the RGB cluster to be scaled simultaneously by the same factor. The scaling factor parameter *u8Level* can be set to a value in the range 0 to 255. Once the function has been called, the brightness of each LED becomes  $u8Level/255$  of its original brightness (the brightness with no global scaling factor applied). The default value of *u8Level* is 255, corresponding to full brightness. A factor of 0 will extinguish the LEDs.

This feature is useful when the LEDs of the RGB cluster are set to different brightness levels in order to achieve a certain colour. The function allows the brightness of the LED cluster to be adjusted without affecting this colour.

Note that when calling the function multiple times, on each occasion the scaling factor is applied to the original brightness levels of the LED cluster. For example, calling the function first with a scaling factor of 128 will result in a brightness reduction to approximately 50% of the original brightness. Then calling the function again with a scaling factor of 192 will result in a brightness increase to approximately 75% of the original brightness.

Also note that the scaling factor is applied to channels 3-7 of the PCA9634 driver device (that may drive PWM outputs on header CN6), as well as to channels 0-2 used for the RGB cluster.



**Note:** The function **bRGB\_LED\_SetGroupLevel()** is identical to **bPCA9634\_SetGroupLevel()** and may be called instead of this one.

### Parameters

*u8Level*                      Brightness scaling factor in the range 0 to 255

### Returns

One of:  
TRUE - scaling factor successfully applied  
FALSE - scaling factor not applied

---

## **bWhite\_LED\_Enable**

---

```
bool bWhite_LED_Enable(void);
```

### **Description**

This function is used to initialise the PWM Timers and DIO for driving the White LED cluster. This function must be called before using any other White LED cluster function.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## **bWhite\_LED\_Disable**

---

```
bool bWhite_LED_Disable(void);
```

### **Description**

This function is used to disable control of the White LED cluster.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## bWhite\_LED\_SetLevel

---

```
bool bWhite_LED_SetLevel(uint8 u8BrightnessLevel);
```

### Description

This function can be used to set the White LED brightness level in the range 0 (dimkest) to 255 (brightest).

### Parameters

*u8BrightnessLevel*    Brightness level (0-255)

### Returns

TRUE - success

FALSE - fail

---

## **bWhite\_LED\_On**

---

```
bool bWhite_LED_On(void);
```

### **Description**

This function can be used to switch on the White LED cluster. The White LED brightness level will be set to the value previously configured using **bWhite\_LED\_SetLevel()**.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## **bWhite\_LED\_Off**

---

```
bool bWhite_LED_Off(void);
```

### **Description**

This function can be used to switch off the White LED cluster.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

**Chapter 4**  
**LED Functions**

## 5. Button Functions

The chapter describes the functions that can be used to interact with a general-purpose button on a Carrier Board:

- On **DR1174**, this button is SW1 but labelled **DIO8** on the board
- On **OM15028**, this button is SW2 but also labelled **GPIO4** on the board

The above boards also have a reset button that cannot be accessed by these functions.

The functions are defined in the header file **Button.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028).



**Note:** The four buttons SW1-SW4 on an LCD Expansion Board and on a Generic Expansion Board (which can be mounted on a carrier board) require their own sets of functions, which are detailed in [Chapter 6](#) and [Chapter 7](#) respectively.

The button functions are listed below, along with their page references:

<b>Function</b>	<b>Page</b>
<a href="#">vButtonInitRfd</a>	<a href="#">44</a>
<a href="#">vButtonInitFfd</a>	<a href="#">45</a>
<a href="#">u8ButtonReadRfd</a>	<a href="#">46</a>
<a href="#">u8ButtonReadFfd</a>	<a href="#">47</a>

---

## vButtonInitRfd

---

```
void vButtonInitRfd(void);
```

### Description

This function is used to initialise the general-purpose button on a Carrier Board and must be called before attempting to access the button.



**Tip:** Either **vButtonInitRfd()** or **vButtonInitFfd()** can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.



**Note:** Different initialisation functions must be used for the four buttons on an LCD Expansion Board and Generic Expansion Board - these functions are **vLcdButtonInit()** and **vGenericButtonInit()**, described on pages [75](#) and [81](#) respectively.

### Parameters

None

### Returns

None

---

## vButtonInitFfd

---

```
void vButtonInitFfd(void);
```

### Description

This function is used to initialise the general-purpose button on a Carrier Board and must be called before attempting to access the button.



**Tip:** Either **vButtonInitFfd()** or **vButtonInitRfd()** can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.



**Note:** Different initialisation functions must be used for the four buttons on an LCD Expansion Board and Generic Expansion Board - these functions are **vLcdButtonInit()** and **vGenericButtonInit()**, described on pages [75](#) and [81](#) respectively.

### Parameters

None

### Returns

None

---

## u8ButtonReadRfd

---

```
uint8 u8ButtonReadRfd(void);
```

### Description

This function can be used to obtain the current state of the general-purpose button on a Carrier Board (SW1/DIO8 on DR1174 or SW2/GPIO4 on OM15028).

The state (pressed or not pressed) of the button is returned in a single bitmap. To obtain the state of button, the returned bitmap must be logical-ANDed with the mask `BUTTON_0_MASK`. A non-zero result indicates that the button is pressed and a zero result indicates that it is not pressed.

Note that there is no de-bounce circuit or algorithm employed.

Before using this function, the button initialisation function `vButtonInitFfd()` or `vButtonInitRfd()` must have been called.



**Tip:** Either `u8ButtonReadRfd()` or `u8ButtonReadFfd()` can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.

### Parameters

None

### Returns

Bitmap containing the state of the button (see above)

---

## u8ButtonReadFfd

---

```
uint8 u8ButtonReadFfd(void);
```

### Description

This function can be used to obtain the current state of the general-purpose button on a Carrier Board (SW1/DIO8 on DR1174 or SW2/GPIO4 on OM15028).

The state (pressed or not pressed) of the button is returned in a single bitmap. To obtain the state of button, the returned bitmap must be logical-ANDed with the mask `BUTTON_0_MASK`. A non-zero result indicates that the button is pressed and a zero result indicates that it is not pressed.

Note that there is no de-bounce circuit or algorithm employed.

Before using this function, the button initialisation function `vButtonInitFfd()` or `vButtonInitRfd()` must have been called.



**Tip:** Either `u8ButtonReadFfd()` or `u8ButtonReadRfd()` can be used, as these functions perform identical operations for the DR1175 and OM15028 Carrier Boards. The two functions have been retained in the Board API for backward compatibility with older boards.

### Parameters

None

### Returns

Bitmap containing the state of the button (see above)

**Chapter 5**  
**Button Functions**

---

## 6. LCD Screen Functions

The chapter describes the functions that can be used to interact with the LCD screen on a DR1201 or DR1215 LCD Expansion Board (both now discontinued).

The functions are defined in the header file **LcdDriver.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028), depending on the type of Carrier Board to which the LCD Expansion Board is fitted.


LCD screen functions that are common to all boards are defined in the header files **LcdDraw.h** and **LcdExtras.h** which are located in the folder **.../Platform/Common/Include**.

---

### 6.1 LCD Screen and Data Display

The LCD screen has a resolution of 64 rows by 128 columns, but is internally arranged so that one byte contains the pixel information for a single column of 8 rows. As a result, the LCD driver is considerably simplified by only allowing the positioning of text or graphics on 8-row boundaries. From now on in this manual, a block of 8 rows will be referred to as a 'character row', with the LCD panel containing 8 character rows. There is no such limitation on the columns.

This principle of data display on the LCD screen is illustrated in the figure below and is described in more detail in [Section 6.1.3](#).



**Figure 1: Data Display on LCD Screen**

---

## 6.1.1 Shadow Memory

The LCD driver uses shadow memory. A screen of information can first be built in the shadow memory and then a command can be issued to update the LCD screen with the contents of shadow memory in one action, thereby improving performance and minimising the possibility of seeing a partially changed screen.

---

## 6.1.2 LCD Font

A proportional font is used to display text on the LCD screen. In this font, most characters are 5 pixels wide, although several characters are narrower than this and some special characters are 7 pixels wide. All characters are 8 pixels high. When printing text, there is a blank column before the first character, between each character and after the last character.

The font is mapped approximately to the ASCII character set, although some characters are moved to simplify the font processing. The map is as follows:

ASCII Code	ASCII Character	LCD Font Character
37	'%'	Percent symbol
38-44	'&',' ',''	Full dark moon – full light moon symbols
48-57	'0'-'9'	'0'-'9'
65-90	'A'-'Z'	'A'-'Z'
91	'['	Degrees symbol
92	'\'	Plus symbol
93	']'	Minus symbol
94	'^'	Space
97-122	'a'-'z'	'a'-'z'

Other characters are displayed as a space.

---

## 6.1.3 LCD Bitmaps

Bitmaps are designed to be simple to render and, as such, map to the way that the LCD screen displays pixels. A bitmap can contain any number of columns but must always be a multiple of 8 pixels high. Each bitmap is treated as a 'C' structure consisting of the width of the bitmap in pixels, its height in character rows and a pointer to an array of bytes containing the pixel data (see the structure below).

```
typedef struct
{
    uint8 *pu8Bitmap;
    uint8 u8Width;
    uint8 u8Height;
} tsBitmap;
```

Consider the bitmap shown below, consisting of 16 rows and y columns. Each pixel is represented by a two-letter name, e.g. ab.

		column					
		0	1	2	..	y-2	y-1
row	0	aa	ab	ac	..	aw	ax
	1	ba	bb	bc	..	bw	bx
	2	ca	cb	cc	..	cw	cx
		..	..	..	..	..	..
	7	ha	hb	hc	..	hw	hx
	8	ia	ib	ic	..	iw	ix
	9	ja	jb	jc	..	jw	jx
		..	..	..	..	..	..
	15	pa	pb	pc	..	pw	px

The first element in the array of pixel data contains the first column of the top character row of pixels, i.e. pu8Bitmap[0] = (MSB) ha ga fa ea da ca ba aa (LSB).

The second element in the array of pixel data contains the second column of the top character row of pixels, i.e. pu8Bitmap[1] = (MSB) hb gb fb eb db cb bb ab (LSB).

This continues until the end of the first character row, so the final column of the first row is in array element y-1, i.e. pu8Bitmap[y-1] = (MSB) hx gx fx ex dx cx bx ax (LSB).

The first column of the second character row of pixels is the next element in the array, i.e. pu8Bitmap[y] = (MSB) pa oa na ma la ka ja ia (LSB).

This row continues until the final column, which will be in element 2y-1, i.e. pu8Bitmap[2y-1] = (MSB) px ox nx mx lx kx jx ix (LSB).

If there are further rows, they repeat in the same manner.

---

## 6.2 Functions

The LCD screen functions are listed below, along with their page references:

Function	Page
<a href="#">vLcdResetDefault</a>	53
<a href="#">vLcdReset</a>	54
<a href="#">vLcdStop</a>	55
<a href="#">vLcdClear</a>	56
<a href="#">vLcdWriteText</a>	57
<a href="#">vLcdWriteTextRightJustified</a>	58
<a href="#">vLcdWriteInvertedText</a>	59
<a href="#">vLcdWriteBitmap</a>	60
<a href="#">vLcdPlotPoint</a>	61
<a href="#">bLcdGetPixel</a>	62
<a href="#">vLcdDrawLine</a>	63
<a href="#">vLcdDrawCircle</a>	64
<a href="#">vLcdFloodFill</a>	65
<a href="#">vLcdRefreshAll</a>	66
<a href="#">vLcdRefreshArea</a>	67
<a href="#">vLcdContrastLevel</a>	68
<a href="#">u8LcdCalcContrastLevel</a>	69
<a href="#">vLcdBackLightEnable</a>	70
<a href="#">vLcdGrabSpiBus</a>	71
<a href="#">vLcdFreeSpiBus</a>	72
<a href="#">vLcdPowerOff</a>	73
<a href="#">vLcdPowerSavingMode</a>	74
<a href="#">vLcdButtonInit</a>	75
<a href="#">u8LcdButtonRead</a>	76



**Note:** The above function set includes functions to interact with the four buttons (SW1-SW4) on an LCD Expansion Board. These buttons do not require the Button functions described in [Chapter 5](#).

---

## vLcdResetDefault

---

```
void vLcdResetDefault(void);
```

### Description

This function is used to initialise the LCD panel using default settings for bias and gain, which should give a good level of contrast. The LCD screen is also cleared.

Alternatively, the LCD panel can be initialised with custom settings for bias and gain using the function **vLcdReset()**.

### Parameters

None

### Returns

None

---

## vLcdReset

---

```
void vLcdReset(uint8 u8Bias, uint8 u8Gain);
```

### Description

This function is used to initialise the LCD panel using the specified settings for bias and gain. The LCD screen is also cleared.

Alternatively, the LCD panel can be initialised with the default settings for bias and gain using the function **vLcdResetDefault()**.

### Parameters

<i>u8Bias</i>	Bias value to use, in the range 0-3
<i>u8Gain</i>	Gain value to use, in the range 0-3

### Returns

None

---

## vLcdStop

---

```
void vLcdStop(void);
```

### Description

This function can be used to power off the LCD screen. The function is normally only used before shutting down the Carrier Board, in order to allow the LCD screen to discharge itself properly.

### Parameters

None

### Returns

None

---

## **vLcdClear**

---

```
void vLcdClear(void);
```

### **Description**

This function can be used to clear the shadow memory of any text or graphics. However, the function does not update the LCD screen itself.

To update the LCD screen from the shadow memory, you can use the function **vLcdResfreshAll()** or **vLcdRefreshArea()**.

### **Parameters**

None

### **Returns**

None

---

## vLcdWriteText

---

```
void vLcdWriteText(char *pcString,  
                  uint8 u8Row,  
                  uint8 u8Column);
```

### Description

This function can be used to write text to the shadow memory.

The text is left-justified, starting at the row and column specified. No attempt is made to prevent the text from spilling over the end of the specified row and if this occurs, the text will wrap around to the next row.

To update the LCD screen from the shadow memory, you can use the function **vLcdResfreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>*pcString</i>	Null-terminated text string to display
<i>u8Row</i>	Character row on which to display text (in the range 0-7)
<i>u8Column</i>	Column in which to start displaying text (in the range 0-127)

### Returns

None

---

## vLcdWriteTextRightJustified

---

```
void vLcdWriteTextRightJustified(char *pcString,  
                                uint8 u8Row,  
                                uint8 u8EndColumn);
```

### Description

This function can be used to write text to the shadow memory.

The text is right-justified, finishing at the row and column specified. No attempt is made to prevent the text from spilling over the start of the specified row and if this occurs, the text will wrap around to the previous row.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>*pcString</i>	Null-terminated text string to display
<i>u8Row</i>	Character row on which to display text (in the range 0-7)
<i>u8Column</i>	Column in which to finish displaying text (in the range 0-127)

### Returns

None

---

## vLcdWriteInvertedText

---

```
void vLcdWriteInvertedText(char *pcString,  
                           uint8 u8Row,  
                           uint8 u8Column);
```

### Description

This function can be used to write inverted text (pixel colours reversed) to the shadow memory.

The text is left-justified, starting at the row and column specified. No attempt is made to prevent the text from spilling over the end of the specified row and if this occurs, the text will wrap around to the next row.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>*pcString</i>	Null-terminated text string to display
<i>u8Row</i>	Character row on which to display text (in the range 0-7)
<i>u8Column</i>	Column in which to start displaying text (in the range 0-127)

### Returns

None

---

## vLcdWriteBitmap

---

```
void vLcdWriteBitmap(tsBitmap *psBitmap,  
                    uint8 u8LeftColumn,  
                    uint8 u8TopRow);
```

### Description

This function can be used to put the specified bitmap into the shadow memory at the specified screen location. If the bitmap goes past the edge of the display area, it is truncated.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>*psBitmap</i>	Pointer to structure containing bitmap information
<i>u8LeftColumn</i>	Left-most column of bitmap (in the range 0-127)
<i>u8TopRow</i>	First character row of bitmap (in the range 0-7)

### Returns

None

---

## vLcdPlotPoint

---

```
void vLcdPlotPoint(uint8 u8X, uint8 u8Y);
```

### Description

This function can be used to plot a point in the shadow memory at the pixel with the specified screen coordinates (x,y). If either x or y is out of range, the pixel cannot be plotted.

To update the LCD screen from the shadow memory, you can use the function **vLcdResfreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>u8X</i>	x-coordinate of pixel to be plotted (in the range 0-127)
<i>u8Y</i>	y-coordinate of pixel to be plotted (in the range 0-63)

### Returns

None

---

## bLcdGetPixel

---

```
bool_t bLcdGetPixel(uint8 u8X, uint8 u8Y);
```

### Description

This function can be used to obtain the status of the pixel at the specified screen coordinates (x,y) in the shadow memory - that is, whether a point has been plotted at the pixel location. If either x or y is out of range, the function returns FALSE.

### Parameters

<i>u8X</i>	x-coordinate of pixel to be checked (in the range 0-127)
<i>u8Y</i>	y-coordinate of pixel to be checked (in the range 0-63)

### Returns

TRUE - point plotted at pixel location  
FALSE - point not plotted at pixel location or invalid screen location specified

---

## vLcdDrawLine

---

```
void vLcdDrawLine(uint8 u8x1,  
                  uint8 u8y1,  
                  uint8 u8x2,  
                  uint8 u8y2);
```

### Description

This function can be used to draw a straight line between two specified screen locations in the shadow memory.

The end-points of the line are specified in terms of coordinates (x1,y1) and (x2,y2). The line is clipped if either of these points lies outside the screen area.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>u8x1</i>	x-coordinate of first end-point of line (in the range 0-127)
<i>u8y1</i>	y-coordinate of first end-point of line (in the range 0-63)
<i>u8x2</i>	x-coordinate of second end-point of line (in the range 0-127)
<i>u8y2</i>	y-coordinate of second end-point of line (in the range 0-63)

### Returns

None

---

## vLcdDrawCircle

---

```
void vLcdDrawCircle(int Xc, int Yc, int Radius);
```

### Description

This function can be used to draw the circle with specified centre and radius in the shadow memory.

The centre of the circle is specified in terms of coordinates (Xc,Yc). The circle is clipped if any points on its circumference lie outside the screen area.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>Xc</i>	x-coordinate of circle centre (in the range 0-127)
<i>Yc</i>	y-coordinate of circle centre (in the range 0-63)
<i>Radius</i>	Radius of circle, in pixels

### Returns

None

---

## vLcdFloodFill

---

```
void vLcdFloodFill(int i32x, int i32y);
```

### Description

This function can be used to perform a 'flood fill' of a screen region in shadow memory - that is, all pixels within the region will be plotted (black).

The region to be filled must have been pre-defined as a closed boundary - for example, a circle created using the **vLcdDrawCircle()** function. **vLcdFloodFill()** requires any starting point to be specified inside but not on the boundary. If the boundary is not closed, the fill will 'leak' and corrupt the display.

To update the LCD screen from the shadow memory, you can use the function **vLcdRefreshAll()** or **vLcdRefreshArea()**.

### Parameters

<i>i32x</i>	x-coordinate of starting point (in the range 0-127)
<i>i32y</i>	y-coordinate of starting point (in the range 0-63)

### Returns

None

---

## **vLcdRefreshAll**

---

```
void vLcdRefreshAll(void);
```

### **Description**

This function can be used to copy the contents of shadow memory to the LCD panel and therefore to refresh the entire screen contents. This copy takes approximately 4.5 ms.

Alternatively, to update a rectangular portion of the LCD screen from the shadow memory, use the function **vLcdRefreshArea()**.

### **Parameters**

None

### **Returns**

None

---

## vLcdRefreshArea

---

```
void vLcdRefreshArea(uint8 u8LeftColumn,  
                    uint8 u8TopRow,  
                    uint8 u8Width,  
                    uint8 u8Height);
```

### Description

This function can be used to copy the contents of the specified rectangle in shadow memory to the appropriate part of the LCD screen without disturbing the rest of the display.

The rectangular screen area to refresh is specified in terms of the left-most column, the top row, the width and the height of the rectangle.

Alternatively, to update the entire LCD screen from shadow memory, use the function **vLcdRefreshAll()**.

### Parameters

<i>u8LeftColumn</i>	Left-most column of rectangle (in the range 0-127)
<i>u8TopRow</i>	First character row of rectangle (in the range 0-7)
<i>u8Width</i>	Number of columns in width of rectangle (in the range 1-128)
<i>u8Height</i>	Number of rows in height of rectangle (in the range 1-8)

### Returns

None

---

## **vLcdContrastLevel**

---

```
void vLcdContrastLevel(uint8 u8Gain);
```

### **Description**

This function can be used to control the contrast level of the LCD screen.

### **Parameters**

*u8Gain*                      Contrast level (in the range 0-15 maximum)

### **Returns**

None

---

## u8LcdCalcContrastLevel

---

```
uint8 u8LcdCalcContrastLevel(void);
```

### Description

This function can be used to calculate the correct contrast level required for the LCD screen. The correct LCD contrast level may then be subsequently set by using the return value of this function as the input parameter value in the call to function **vLCDContrastLevel()**.

### Parameters

None

### Returns

Contrast level (in the range 0-15)

---

## **vLcdBackLightEnable**

---

```
void vLcdBackLightEnable(uint8 u8Status);
```

### **Description**

This function can be used to control the LCD back-light.

### **Parameters**

<i>u8Status</i>	0 - Disable (switch off) the LCD back-light 1 - Enable (switch on) the LCD back-light Note, all other values will have no effect.
-----------------	---

### **Returns**

None

---

## vLcdGrabSpiBus

---

```
void vLcdGrabSpiBus(void);
```

### Description

This function can be used to take control of the SPI bus for the LCD panel.

### Parameters

None

### Returns

None

---

## **vLcdFreeSpiBus**

---

```
void vLcdFreeSpiBus(void);
```

### **Description**

This function can be used to free control of the SPI bus for the LCD panel.

### **Parameters**

None

### **Returns**

None

---

## vLcdPowerOff

---

```
void vLcdPowerOff(void);
```

### Description

This function can be used to power off the LCD screen. The function is normally only used before shutting down the LCD screen of the LCD Expansion Board, in order to allow the LCD screen to discharge itself properly.

### Parameters

None

### Returns

None

---

## **vLcdPowerSavingMode**

---

```
void vLcdPowerSavingMode(bool_t bSelectMode);
```

### **Description**

This function can be used to control the LCD screen power-saving mode.

### **Parameters**

<i>bSelectMode</i>	TRUE - Power-saving mode ON FALSE - Power-saving mode OFF
--------------------	--

### **Returns**

None

---

## vLcdButtonInit

---

```
void vLcdButtonInit(void);
```

### Description

This function can be used to initialise access to the four buttons (SW1-SW4) on the LCD Expansion Board (DR1215 or DR1201).



**Note:** Access to the general-purpose button on the underlying Carrier Board (DR1174 or OM15028) can be initialised using the function **vButtonInitFfd()** or **vButtonInitRfd()**, described in [Chapter 5](#).

### Parameters

None

### Returns

None

---

## u8LcdButtonRead

---

```
uint8 u8LcdButtonRead(void);
```

### Description

This function can be used to read the current state of the four buttons SW1-SW4 on the LCD Expansion Board (DR1215 or DR1201). Before using this function, the initialisation function **vLcdButtonInit()** must have been called.



**Note:** The general-purpose button on the underlying Carrier Board (DR1174 or OM15028) can be read using the function **u8ButtonReadFfd()** or **u8ButtonReadRfd()**, described in [Chapter 5](#).

### Parameters

None

### Returns

A bitmap that represents the status of the buttons (1 indicates a button-press)

Bit 0-3: SW1-SW4 status

Button	Value	Enumeration
SW1	1	LCD_BOARD_BUTTON_S1_VAL
SW2	2	LCD_BOARD_BUTTON_S2_VAL
SW3	4	LCD_BOARD_BUTTON_S3_VAL
SW4	8	LCD_BOARD_BUTTON_S4_VAL

Bit 4-7: Unused

## 7. Generic Board (DR1199) Functions

This chapter describes the functions that can be used to interact with the specific resources provided by the DR1199 Generic Expansion Board.

The Generic Expansion Board provides the following resources:

- 50kohm potentiometer (R4)
- 4 x push-button (SW1-SW4)
- 3 x LED (D1-D3)

The potentiometer is connected in series with a 33kohm resistor (R8) to form a potential divider between the supply and ground. The voltage across the potentiometer may be measured by the JN51xx device using the on-chip ADC.

It is possible to fit a fourth LED (D4) to the board, but for correct operation this will require removal of the fourth push button (SW4) because these components share the same IO pin.

The functions described in this chapter are provided to simplify the use of these hardware resources and resolve the device IO connections for this board - for example, SW1 on this board is not assigned to the same DIO pin as on the older DR1047 board.

The functions are defined in the header file **GenericBoard.h**, located in the folder **.../Platform/DK4/Include** (for DR1174) or **.../Platform/DK5/Include** (for OM15028), depending on the type of Carrier Board to which the Generic Expansion Board is fitted.

The functions are listed below, along with their page references:

Function	Page
<a href="#">bPotEnable</a>	78
<a href="#">u16ReadPotValue</a>	79
<a href="#">bPotDisable</a>	80
<a href="#">vGenericButtonInit</a>	81
<a href="#">u8GenericButtonRead</a>	82
<a href="#">vGenericLEDInit</a>	83
<a href="#">vGenericLEDSetOutput</a>	84



**Note:** The above function set includes functions to interact with the four buttons (SW1-SW4) on a Generic Expansion Board. These buttons do not require the Button functions described in [Chapter 5](#).

## **bPotEnable**

---

```
bool_t bPotEnable(void);
```

### **Description**

This function is used to configure the IO and on-chip ADC for reading the voltage across the potentiometer on the Generic Expansion Board. This function should be called before using any other potentiometer function.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## u16ReadPotValue

---

```
uint16 u16ReadPotValue(void);
```

### Description

This function can be used to read the voltage across the potentiometer on the Generic Expansion Board as measured by the on-chip ADC.

Before using this function, the potentiometer initialisation function **bPotEnable()** must have been called.

### Parameters

None

### Returns

ADC reading of voltage measured across potentiometer (10-bit value for both JN516x and JN517x)

## **bPotDisable**

---

```
bool_t bPotDisable(void);
```

### **Description**

This function can be used to disable the IO and on-chip ADC from reading the voltage across the potentiometer on the Generic Expansion Board.

Before using this function, the potentiometer initialisation function **bPotEnable()** must have been called.

### **Parameters**

None

### **Returns**

TRUE - success

FALSE - fail

---

## vGenericButtonInit

---

```
void vGenericButtonInit(void);
```

### Description

This function is used to configure the IO for reading the status of the push-buttons on the Generic Expansion Board. This function should be called before using any other push-button function for this board.



**Note:** Access to the general-purpose button on the underlying Carrier Board (DR1174 or OM15028) can be initialised using the function **vButtonInitFfd()** or **vButtonInitRfd()**, described in [Chapter 5](#).

### Parameters

None

### Returns

None

---

## u8GenericButtonRead

---

```
uint8 u8GenericButtonRead(void);
```

### Description

This function can be used to read the status of the four buttons SW1-SW4 on the Generic Expansion Board. Before using this function, the initialisation function **vGenericButtonInit()** must have been called.



**Note:** The general-purpose button on the underlying Carrier Board (DR1174 or OM15028) can be read using the function **u8ButtonReadFfd()** or **u8ButtonReadRfd()**, described in [Chapter 5](#).

### Parameters

None

### Returns

A bitmap that represents the status of the buttons (1 indicates a button-press)

Bit 0-3: SW1-SW4 status

Button	Value	Enumeration
SW1	1	GEN_BOARD_BUTTON_S1_VAL
SW2	2	GEN_BOARD_BUTTON_S2_VAL
SW3	4	GEN_BOARD_BUTTON_S3_VAL
SW4	8	GEN_BOARD_BUTTON_S4_VAL

Bit 4-7: Unused

---

## vGenericLEDInit

---

```
void vGenericLEDInit(void);
```

### Description

This function is used to configure the IO for driving the LEDs on the Generic Expansion Board. This function should be called before using any other LED function for this board.

### Parameters

None

### Returns

None

---

## vGenericLEDSetOutput

---

```
void vGenericLEDSetOutput(uint8 u8LEDBitmap, bool_t bOn);
```

### Description

This function can be used to control the status of the four LEDs D1-D4 on the Generic Expansion Board. Before using this function, the initialisation function **vGenericLEDInit()** must have been called.

### Parameters

<i>u8LEDBitmap</i>	Bitmap of LEDs to control (bit 0-3: D1-D4, bit 4-7: unused) - the following enumerations can be used: GEN_BOARD_LED_D1_VAL (1) GEN_BOARD_LED_D2_VAL (2) GEN_BOARD_LED_D3_VAL (4) GEN_BOARD_LED_D4_VAL (8)
<i>bOn</i>	Status that the LEDs should be set to (TRUE: On, FALSE: Off)

### Returns

None

## Revision History

Version	Date	Comments
1.0	12-Sep-2005	First release
1.1	14-Nov-2005	Updated document style
1.2	10-Mar-2006	Removed references to specific evaluation kit
1.3	06-Oct-2006	Name of API changed from Evaluation Kit Library to Board API
1.4	08-Jan-2007	Updated for JN513x chip series
2.0	22-Nov-2010	Manual re-worked in new template and API re-named the Low-Power Radio Frequency (LPRF) Board API. JN5148 chip added and minor corrections made
2.1	18-Sept-2012	Updated to include DR1174 and DR1175 boards. JN5142 chip also added and other minor changes made
2.2	17-Dec-2012	Updated to include DR1199 and DR1201 boards. JN516x chip family also added and SDK information updated.
2.3	18-Dec-2013	LCD Expansion Board DR1201 replaced with DR1215
2.4	31-Oct-2016	Updated to include OM15028 carrier board for the JN517x chip family and to remove JN5139/4x chips and associated boards. Other minor changes also made.

## Important Notice

**Limited warranty and liability** - Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the *Terms and conditions of commercial sale* of NXP Semiconductors.

**Right to make changes** - NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** - NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** - Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Export control** - This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

## NXP Semiconductors

For online support resources and contact details of your local NXP office or distributor, refer to:

[www.nxp.com](http://www.nxp.com)