

---

## Release Notes

---

# S32 Design Studio for Power Architecture v1.1

### TABLE OF CONTENTS

1	Release description .....	2
1.1	Release content.....	2
2	What's New .....	3
3	System Requirements .....	3
3.1	Recommended Configuration.....	3
3.2	Operational Minimum Configuration .....	4
3.3	Host Operating System Support.....	4
4	Product WEB page .....	4
5	Installation and Licensing .....	4
6	Technical Support.....	5
	Appendix A: Known issues and Workarounds .....	6
	Appendix B: Performance Considerations .....	8

## 1 Release description

Freescale, a subsidiary of NXP Semiconductors, is pleased to announce the release of the S32 Design Studio for Power Architecture v1.1 for Automotive and Ultra-Reliable MCUs. The S32 Design Studio is based on the Eclipse open development platform and integrates the Eclipse IDE, GNU Compiler Collection (GCC), GNU Debugger (GDB), and other open-source software to offer designers a straightforward development tool with no code-size limitations.

### 1.1 Release content

- Eclipse Luna 4.4 Framework
- GNU Build Tools for e200 processors (support VLE and BookE ISA, based on gcc 4.9.2, binutils 2.24 and gdb 7.8.2)
- Libraries included: newlib, newlib-nano and Freescale EWL2
- P&E Multilink/Cyclone (with P&E GDB Server)
- New Project wizard to create application and library projects for supported devices
- Peripherals Register View
- Graphical tool for creating SPT algorithms
- SDK management included:
  - FreeMaster Serial Communication driver for 560xP family
  - Automotive Math and Motor Control Libraries
- GreenHills and Diab compilers support by new project wizard
- Lauterbach and PLS debuggers support by new project wizard
- Kernel Aware debugging for FreeRTOS, eCOS, OSEK.
- Devices supported:
  - S32R274
  - MPC5775K, MPC5774K
  - MPC5746R, MPC5745R, MPC5743R
  - MPC5777M
  - MPC5777C
  - MPC5748G, MPC5747G, MPC5746G
  - MPC5746C, MPC5745C, MPC5746D, MPC5746B, MPC5745D, MPC5745B
  - MPC5744P, MPC5743P, MPC5742P, MPC5741P
  - MPC5601P, MPC5602P, MPC5603P, MPC5604P
  - MPC5644B, MPC5644C, MPC5645B, MPC5645C, MPC5646B, MPC5646C
  - MPC5601D, MPC5602B, MPC5602C, MPC5602D, MPC5603B, MPC5603C, MPC5604B, MPC5604C, MPC5605B, MPC5606B, MPC5607B

- MPC5606S
- MPC5604E
- MPC5644A
- MPC5643L
- MPC5676R

## 2 What's New

S32 Design Studio for Power Architecture v1.1 addresses a number of defects and new features:

### 2.1 New device support

- S32R274
- MPC5604E
- MPC5644A
- MPC5643L
- MPC5676R

### 2.2 New features

- SPT graphical tool
- Support for BookE, LSP, SPE/SPE2 added to compiler
- SDK management included:
  - FreeMaster Serial Communication driver for 560xP family
  - Automotive Math and Motor Control Libraries
- GreenHills and DIAB compilers supported by new project wizard
- Lauterbach and PLS debuggers supported by new project wizard
- Kernel Aware debugging for FreeRTOS, eCOS, OSEK.
- Examples included:
  - Single Elf example of multicore project
  - Example with Bootloader is provided for MPC5748G device
- Command “New S32DS project from” added to support project creating from examples

## 3 System Requirements

### 3.1 Recommended Configuration

- 2.6GHz Pentium® compatible processor or better
- 4GB RAM
- 3.5 GB

- 400MB on Windows system disk
- USB port for communications with target hardware
- Ethernet port for communications with target hardware (optional)

### **3.2 Operational Minimum Configuration**

- 1.8GHz Pentium® compatible processor or better
- 2GB RAM
- 3.5 GB
- 400MB on Windows system disk
- USB port for communications with target hardware

### **3.3 Host Operating System Support**

- Microsoft Windows 7 32-bit and 64-bit (Home Premium Edition and Professional Edition)
- Microsoft Windows 8 32-bit and 64-bit (Home Premium Edition and Professional Edition)
- Microsoft Windows 8.1 32-bit and 64-bit (Home Premium Edition and Professional Edition)
- Microsoft Windows 10 32-bit and 64-bit (Home and Pro Editions)

## **4 Product WEB page**

S32 Design Studio for Power Architecture v1.1 product page is <http://www.nxp.com/S32DS>. It contains general information about this product, updates, and download links.

## **5 Installation and Licensing**

To install S32 Design Studio for Power Architecture v1.1, choose the download option that meets your needs.

The installer package contains the complete S32 Design Studio for Power Architecture v1.1 suite and an installer. All data needed by the installer will be downloaded and no other download will be performed. Double-click the installation package and a wizard will guide you through the installation process.

During installation the license activation will be requested. The following types of activation supported:

- Online activation, requires the internet access and request for license will be sent automatically
- Offline activation, no internet access required, the offline activation request is generated and should be passed to licensing site to get the activation response, which should be loaded back to installer.

New functionality including support for new devices can be added to S32 Design Studio for Power Architecture v1.1 with service packs, updates and patches. Service packs add specific support for new devices. Updates and patches correct software defects and add general functionality affecting more than one device family.

New support can be added directly from the Internet or from a downloaded archive. If your computer is connected to the Internet, select Install New Software in the Help Menu and all available updates will be displayed. If your computer does not have Internet access, you can download the archive that

contains the service pack, update or patch you need from product page and follow the Service Pack Updater procedure posted on the site.

## **6 Technical Support**

S32 Design Studio issues are tracked through the S32DS Public NXP Community space.

<https://community.freescale.com/community/s32/s32ds>

For confidential cases and cases which cannot be publicly shared on NXP Community please follow the steps described here:

<https://community.freescale.com/docs/DOC-329745>

## Appendix A: Known issues and Workarounds

There are some issues which are introduced by CDT therefore reproduced in S32 Design Studio. Those issues might be fixed when the fix is available with newer CDT version and when S32 Design Studio migrates to it.

- **Incorrect display of the resource excluded** in some build configuration even when corresponding build configuration set active, always show state for the first configuration.  
**Workaround:** use the Build Configurations dialog to see the correct inclusion and exclusion for resources (files and folders). Select “Build Configurations...” menu item in local project menu.
- **Conditional watchpoints and breakpoints:** Conditional breakpoints and watchpoints, including those using ignore counts, do not work always.  
**Workaround:** do not use conditions for breakpoints and watchpoints, instead check for condition in the code and set a normal breakpoint.
- **Renamed/copied project** launch configuration is not updated automatically  
**Workaround:** Project and C/C++ Application parameters should be updated in the Debug Configurations dialog. Please note that if project is renamed or original project is removed – then the launch configuration could be filtered – you need to temporary uncheck Filter Deleted/Unavailable Projects.
- **Uninstallation of P&E drivers:** The P&E Device Drivers item will remain in the Control Panel/ Programs and Features after uninstallation of S32 Design Studio, if user will try to use this item to uninstall – error message appeared, the user should ignore it. But the drivers will remain in the system.  
**Workaround:** P&E drivers should be uninstalled before the product uninstallation. But one should be careful if several products are using P&E drivers.
- **Reset/Restart multicore debug session:** When the restart of multicore debug session is performed , debug sessions for secondary cores stop being valid.  
**Workaround:** The debug session for secondary cores should be terminated and started again to re-attach to core.
- **Debugger** might fail for MPC5777M when stopped on main() and memory window opened at address 0xFFE68000 and step performed (before initialization done).  
**Workaround:** Open memory window at that address after xcptn\_xmpl() is executed.
- **Disassembly view** content might be destroyed occasionally.  
**Workaround:** Close disassembly view and open it again using menu Window → Show View → Disassembly.
- **USB driver conflict between P&E and Xilinx software:** P&E Drivers for Windows utilize the 3rd party service Jungo Windriver to enable USB support under windows XP/7/8.x/10. Xilinx also uses Windriver for their driver packages, but older versions. Starting with the P&E Driver package 11.7, a conflict between P&E Drivers and software IDEs that rely on older Jungo driver packages might occur. This is because both the old and new driver packages utilize the same .sys file (windrvr6.sys). When the new P&E Drivers are installed, Xilinx tools stop working after 30 days because the new sys file requires a new license that the older Xilinx software does not have.  
**Workaround:** Please follow the steps in P&E's FAQ 255 for installing an older version of P&E Drivers (11.1) to resolve Xilinx conflict under Windows XP/7/8.x.  
[http://www.pemicro.com/website\\_management/faq\\_view.cfm?id=225](http://www.pemicro.com/website_management/faq_view.cfm?id=225)  
If drivers issue persists, please submit a support request to P&E Microcomputer Systems:  
<http://www.pemicro.com/support/index.cfm>

- **Missing license** could be reported on IDE start.  
**Workaround:** same activation ID should be entered.
- **Hyperlinks** might not work correctly under Windows 10 when Microsoft Edge is default browser  
**Workaround:** Set another browser as default.
- **SPE2 support limitations** by compiler:
  - SPE2 intrinsic functions are not implemented.**Workaround:** Use inline assembler
- **SPE2 support limitations** by tools:
  - Disassembler doesn't show SPE2 instructions mnemonics.**Workaround:** None. Only opcodes are displayed
- **LSM or DPM device mode selection for MPC5643L:** MPC5643L device provides user with capability to configure the processor to boot up in Lock-Step Mode (LSM) or Dual-Processor Mode(DPM) out of reset. One is required to re-flash a dedicated control byte in shadow block of FLASH memory to switch back and forth between LSM and DPM modes  
**Workaround:** This can be safely achieved by using a dedicated FLASH programming algorithm within evaluation version of PROGPPCNEXUS FLASH programming software from P&E Microcomputer Systems. Please refer to the following FAQ for a download link and step by step LSM/DPM mode switching directions -  
[http://www.pemicro.com/website\\_management/faq\\_view.cfm?id=227](http://www.pemicro.com/website_management/faq_view.cfm?id=227)

## Appendix B: Performance Considerations

The following suggestions will help keep the S32 Design Studio tools running at a respectable performance level.

- 1 To maximize performance, the S32 Design Studio tools should be installed on a computer with the recommended system configuration. While the tools will operate on a computer with the minimum configuration, the limited hardware will restrict its ability to function at desired performance levels.
- 2 Close unused projects. Eclipse caches files for all open projects in the workspace. If you need multiple projects open, try to limit the number of projects to no more than 10.
- 3 The Eclipse IDE provides several options that provide user assistance tools. These options, however, use memory and cpu bandwidth. If performance is slow and you do not need these options, turn them off.
  - Scalability options configure how eclipse deals with large source files.
    - Scalability options:
      - Editor live parsing: impacts parsing while typing, Outline View, semantic highlighting, folding, etc.
      - Semantic highlighting: C/C++ identifiers are colored
      - Syntax coloring: coloring of keywords, comments and literals
      - Parsing-based content assist proposals: content assist proposals which require parsing the file
      - Content assist auto activation: content assist activated automatically on trigger sequences, like '.', '::' or '->'.
    - To disable:
      - Click menu 'Window' -> 'Preference'
      - Expand 'C/C++' -> 'Editor' -> 'Scalability'
      - Uncheck 'Enable all scalability mode options'
  - Content Assist Auto Activation can reduce the number of keystrokes a developer must type to create code. The Content Assist plug-in consists of components that predict what a developer will type, based on the current context, scope and prefix.
    - To disable:
      - Click menu 'Window' -> 'Preference'
      - Expand 'C/C++' -> 'Editor' -> 'Content Assist'
      - Uncheck all the options for 'Auto-Activation'