




# HVBMS Battery Junction Box (BJB)

## HVBMS-BJB


Last Updated: Feb 7, 2024

The battery junction box (BJB) is the controlling part of the BMS. It measures several high-voltages throughout the overall BMS, accurately and redundantly measures the system's current and measures isolation resistance between the battery and the chassis for isolation monitoring.


## HBMS-BJB - 400 V using ETPL Block Diagram



## HBMS-BJB - 400 V using CAN Block Diagram



# HVBMS-BJB - 800 V using ETPL Block Diagram



View additional information for [HVBMS Battery Junction Box \(BJB\)](#).

Note: The information on this document is subject to change without notice.

[www.nxp.com](http://www.nxp.com)

NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. © 2024 NXP B.V.