

Document Number: MHW7342 Rev. 1, 11/2003

CATV Amplifier Module

Features

- Specified for up to 112-Channel Loading
- Excellent Distortion Performance
- Superior Gain, Return Loss and DC Current Stability over Temperature
- Silicon Bipolar Transistor Technology
- Unconditionally Stable Under All Load Conditions

Applications


- CATV Systems Operating in the 40 to 750 MHz Frequency Range
- Single Module High Gain Line Amplifier in Cable TV Distribution System

Description

• 24 Vdc Supply, 40 to 750 MHz, CATV High Gain Forward Amplifier Module

MHW7342

750 MHz 35.2 dB GAIN 112-CHANNEL CATV AMPLIFIER MODULE



CASE 1302-01, STYLE 1

Table 1. Maximum Ratings

ARCHIVE INFORMATION

| Rating | Symbol | Value | Unit |
|----------------------------------|-------------------------------|--------------|------|
| RF Voltage Input (Single Tone) | V _{in} | + 55 | dBmV |
| DC Supply Voltage | y Voltage V _{CC} +28 | | Vdc |
| Operating Case Temperature Range | Т _С | - 20 to +100 | °C |
| Storage Temperature Range | T _{stg} | - 40 to +100 | °C |

Table 2. Electrical Characteristics (V_{CC} = 24 Vdc, T_C = +30°C, 75 Ω system unless otherwise noted)

| Characteristic Frequency Range | | Symbol | Min | Тур | Max 750 | Unit MHz |
|--|---|----------------|----------------------|----------------------|-------------------|-------------|
| | | BW | 40 | | | |
| Power Gain | 50 MHz 750 MHz | G _p | 33.2 33.8 | 34 35.2 | 34.8 36 | dB |
| Slope | 40 - 750 MHz | S | 0.3 | 1.2 | 2.25 | dB |
| Gain Flatness (Peak To Valley) | | G _F | _ | 0.3 | 0.8 | dB |
| Return Loss — Input (Z _o = 75 Ohms) | 40-80 MHz 80-320 MHz 320-640 MHz 640-750 MHz | IRL | 22 18 16 14 | 28 25 22 19 | | dB |
| Return Loss — Output (Z _o = 75 Ohms) | 40-80 MHz 80-240 MHz 240-640 MHz 640-750 MHz | ORL | 22 19 17 15 | 28 25 22 22 | | dB |







| 79-Channel FLAT 112-Channel FLAT 79-Channel FLAT | CSO ₇₉ CSO ₁₁₂ | | - 65 - 55 | - 57 - 50 | dBc dBc |
|--|---|---|---|---|---|
| | VMD | | | | dBo |
| 112-Channel FLAT | XMD ₇₉ XMD ₁₁₂ | _ | - 63 - 56 | - 60 - 53 | ubc |
| 79-Channel FLAT 112-Channel FLAT | CTB ₇₉ CTB ₁₁₂ | | - 64 - 54 | - 62 - 52 | dBc |
| 50 MHz 550 MHz 750 MHz | NF | | 3.5 4.5 5 | 4.5 — 6 | dB |
| | I _{DC} | 310 | 325 | 350 | mA |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | 112-Channel FLAT 50 MHz 550 MHz | 112-Channel FLATCTB11250 MHzNF550 MHzNF | 112-Channel FLAT CTB ₁₁₂ — 50 MHz NF — 550 MHz — — 750 MHz — — | 112-Channel FLAT CTB ₁₁₂ - 54 50 MHz NF 3.5 550 MHz 4.5 750 MHz 5 | 112-Channel FLAT CTB ₁₁₂ -54 -52 50 MHz NF 3.5 4.5 550 MHz 4.5 750 MHz 5 6 |



PACKAGE DIMENSIONS



ARCHIVE INFORMATION



CASE 1302-01 ISSUE B NOTES:

 DIMENSIONS ARE IN INCHES.
INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5M, 1994.

| | INCHES | | MILLIMETERS | | |
|-----|-----------|-------|-------------|--------|--|
| DIM | MIN | MAX | MIN | MAX | |
| Α | | 1.775 | | 45.085 | |
| В | | 1.085 | | 27.559 | |
| С | | 0.840 | | 21.336 | |
| D | 0.015 | 0.021 | 0.381 | 0.533 | |
| E | 0.465 | 0.510 | 11.811 | 12.954 | |
| F | 0.300 | 0.325 | 7.62 | 8.255 | |
| G | 0.100 BSC | | 2.540 BSC | | |
| J | 0.156 BSC | | 3.962 BSC | | |
| Κ | 0.315 | 0.355 | 8.001 | 9.017 | |
| L | 1.000 BSC | | 25.400 BSC | | |
| Ν | 0.165 BSC | | 4.191 BSC | | |
| Ρ | 0.100 BSC | | 2.540 BSC | | |
| Q | 0.148 | 0.168 | 3.759 | 4.267 | |
| R | | 0.600 | | 15.24 | |
| S | 1.500 BSC | | 38.100 BSC | | |
| U | 0.200 BSC | | 5.080 BSC | | |
| V | | 0.250 | | 6.350 | |
| W | 0.435 | | 11.049 | | |
| Х | 0.400 BSC | | 10.160 BSC | | |
| Y | 0.152 | 0.163 | 3.861 | 4.140 | |
| Ζ | 0.009 | 0.011 | 0.229 | 0.279 | |

STYLE 1: PIN 1. RF INPUT 2. GROUND 3. GROUND 4. DELETED 5. VDC 6. DELETED 7. GROUND 8. GROUND 9. RF OUTPUT

RF Device Data

Freescale Semiconductor



How to Reach Us:

Home Page: www.freescale.com

E-mail: support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor Technical Information Center, CH370 1300 N. Alma School Road Chandler, Arizona 85224 +1-800-521-6274 or +1-480-768-2130 support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064 Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd. Technical Information Center 2 Dai King Street Tai Po Industrial Estate Tai Po, N.T., Hong Kong +800 2666 8080 support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center P.O. Box 5405 Denver, Colorado 80217 1-800-441-2447 or 303-675-2140 Fax: 303-675-2150 LDCForFreescaleSemiconductor@hibbertgroup.com Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

Freescale [™] and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2003, 2006. All rights reserved.



