

## Freescale Semiconductor

Mask Set Errata

MSE9S08QE32\_0M49M Rev. 2, 5/2010

# Mask Set Errata for Mask 0M49M

## Introduction

This report applies to mask 0M49M for these products:

- MC9S08QE32
- MC9S08QE16

SE184-FLVD-STOP3: False low voltage detect when exiting stop3

Errata type: Silicon

Affected component: SoC level behavior

**Description:** If the low voltage detect (LVD) is enabled (LVDE = 1) but not in stop mode

(LVDSE = 0), on some devices the low voltage detect flag (LVDF) will

occasionally be set when exiting stop3 mode. If the LVD interrupt is enabled (LVDIE = 1) the interrupt vector will be fetched. If the LVD reset is enabled, the part will reset, and the LVD bit in the System Reset Status (SRS) register will be set. The correct operation of the device is to wake and execute the

code immediately after the STOP instruction.

If the LVD is not enabled (LVDE = 0) or if LVD is also enabled during stop mode (LVDSE = 1) then this issue will not occur. If the LVD is enabled during

stop mode the stop3 current will increase.

**Workaround:** A software level change to reliably eliminate the issue is to use only the LVD

interrupt (LVDE = 1, LVDIE = 1, and LVDRE = 0). Inside the LVD interrupt service routine, a short state of health check can be made to verify the supply level before proceeding. In this routine, the LVDF should be cleared and then read to determine whether a true low voltage event is present. If the LVDF is set when it is read, then a true LVD condition exists and the MCU can be

reset by forcing the execution of an illegal op-code.

SE156-ADC-COCO: COCO bit may not get cleared when ADCSC1 is written to

Errata type: Silicon





Affected component: ADC

**Description:** If an ADC conversion is near completion when the ADC Status and Control

1 Register (ADCSC1) is written to (i.e., to change channels), it is possible for the conversion to complete, setting the COCO bit, before the write instruction is fully executed. In this scenario, the write may not clear the COCO bit, and the data in the ADC Result register (ADCR) will be that of the recently

completed conversion.

If interrupts are enabled, then the interrupt vector will be taken immediately

following the write to the ADCSC1 register.

Workaround: It is recommended when writing to the ADCSC1 to change channels or stop

continuous conversion, that you write to the register twice. The first time should be to turn the ADC off and disable interrupts, and the second should

be to select the mode/channel and re-enable the interrupts.



#### How to Reach Us:

### **Home Page:**

www.freescale.com

## Web Support:

http://www.freescale.com/support

#### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor
Technical Information Center, EL516
2100 East Elliot Road
Tempe, Arizona 85284
+1-800-521-6274 or +1-480-768-2130
www.freescale.com/support

#### Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German)

#### Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064 Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

+33 1 69 35 48 48 (French)

www.freescale.com/support

#### Asia/Pacific:

Freescale Semiconductor China Ltd.
Exchange Building 23F
No. 118 Jianguo Road
Chaoyang District
Beijing 100022
China
+86 10 5879 8000
support.asia@freescale.com

# For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center 1-800-441-2447 or +1-303-675-2140 Fax: +1-303-675-2150

LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and sofware implementers to use Freescale Semiconductors products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor prodcuts are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claims alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-complaint and/or non-Pb-free counterparts. For further information, see http://www.freescale.com or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to http://www.freescale.com/epp.

Freescale<sup>TM</sup> and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners.

© 2010 Freescale Semiconductor.

Document Number: MSE9S08QE32\_0M49M

Rev. 2, 5/2010

